



Remote Control Touch User Guide

Version 2.3.1 / 10.03.2016




Table of contents

1	LICENSE AGREEMENT	4
2	PRODUCT LIABILITY	5
3	Overview	6
4	System requirements	7
4.1	Further manuals	7
5	Remote Control Touch	8
5.1	Position of components	8
5.1.1	Top view.....	8
5.1.2	Side view, from the right.....	9
5.1.3	Rear side.....	9
5.2	Functionality of components.....	10
5.2.1	Ports.....	10
5.2.2	Brightness sensor.....	10
5.2.3	Home button.....	10
5.2.4	Speaker.....	10
5.2.5	LEDs	11
5.2.6	Microphone	11
5.2.7	Touchscreen	11
5.3	Accessories.....	11
5.4	Installation	12
5.4.1	Cable connection.....	12
5.4.2	Telemotive System Client.....	13
5.5	Connecting the Remote Control Touch with a data logger.....	15
5.5.1	Configure the network settings	15
5.5.2	Activating Telemotive System Link (TSL)	16
5.6	Resetting the network settings.....	17
6	Surface	18
6.1	Layout of the views.....	19
6.1.1	Header bar	19
6.1.2	Tab bar.....	20
6.2	Applications.....	20
6.3	Tab sheets	21
6.3.1	Overview	21
6.3.2	*Device name n*.....	22
6.3.3	Functionkeys	22
6.3.4	Markerlist.....	23
6.3.5	CAN/Serial/LIN/Ethernet/Camera/CCP_XCP	23
6.3.6	MOST150.....	24
6.3.7	GPS	25
6.3.8	General	26
6.4	Displays.....	27
6.5	Other views	29
6.5.1	AlertDialog.....	29
6.5.2	FW-Update.....	29
6.5.3	Launcher	30
6.5.4	RC Monitor	31
6.5.5	RC Text.....	32
6.5.6	Standby.....	32
6.6	Restrictions in standalone mode.....	33
6.6.1	Remote Control Touch applications.....	33
6.6.2	Telemotive System Client applications	33
7	Operation	36
7.1	Actuating funktionkey	36

7.2	Adjusting backlight	36
7.2.1	Automatic adjustment	36
7.2.2	Manual adjustment	37
7.3	Adjusting volume	37
7.4	Changing application	37
7.5	Changing tab sheet	38
7.6	Opening and closing side menu	38
7.7	Playing voice note	38
7.8	Scrolling through applications.....	39
7.9	Scrolling through tab bar	39
7.10	Scrolling through tab sheet.....	40
7.11	Setting and deleting complex triggers.....	40
7.12	Setting triggers	43
7.12.1	Trigger with voice note.....	43
7.12.2	Trigger without voice note.....	44
7.13	Switching the device off.....	45
7.14	Switching the device on.....	45
7.15	Updating firmware	46
8	Maintenance provisions and safety regulations	49
8.1	Operating conditions.....	49
8.1.1	Temperature.....	49
8.1.2	Condensation	49
8.1.3	Environment	49
8.1.4	Mechanical action.....	50
8.2	Assembly.....	50
8.2.1	Cable sets	50
8.2.2	Mounting	50
8.2.3	Positioning of antenna.....	50
8.3	Proper operation.....	51
9	Data sheet	52
10	Abbreviations	53
11	List of figures.....	54
12	List of tables	56
13	Contact.....	57

1 LICENSE AGREEMENT

Please read the license agreement of this license contract carefully, before you install the software. By the installation of the software you agree to the conditions of this license contract. This software-license agreement, in the following called "license", contains all rights and restrictions for final users that regulate the use of the accompanying software, operating instructions and other documents, in the following called as "software".

1. This license contract is an agreement between licensor and licensee, who is being licensed to use the named software.
2. Licensee acknowledges that this is only a limited nonexclusive license. This means, that the licensee has no right to allocate sublicenses. Licensor is and remains the owner of all titles, rights and interests in the software.
3. The software is a copyright property of the Telemotive AG. The program or parts of it may not be further licensed to third parts, rented, sold or be further marketed in any form without explicit written approval by Telemotive AG. The user may neither change the software and their components, nor modify, nor redevelop or decompile otherwise in any form.
4. This software is subject to no warranty. This software is sold as is, without any warranty. If at any time, a user changes his system, we hold no responsibility to change our software to make it work again.
5. This license permits licensee to install the software on more than one computer system, as long as the software will not be used on more than one computer system simultaneously. Licensee will not make copies of the software or allow copies of the software to be made by others, unless authorized by this license agreement. Licensee may make copies of the software for backup purposes only. Licensee is not entitled to transmit or to transfer the software or its rights from this license agreement.
6. Licensor is not liable to licensee for any damages, including compensatory, special, incidental, exemplary, punitive or consequential damages, connected with or resulting from this license agreement or licensee's use of this software.
7. Licensee agrees to defend and indemnify licensor and hold licensor harmless from all claims, losses, damages, complaints or expenses connected with or resulting from licensee's business operations.
8. Licensor has the right to terminate this license agreement and licensee's right to use this software upon any material breach by licensee. The duration of the license contract is indefinitely determined.
9. Licensee agrees to return all copies of the software to licensor or to destroy them upon termination of the license contract.
10. This license agreement replaces and supersedes all prior negotiations, dealings and agreements between licensor and licensee regarding this software.
11. This license contract is subject to German law.
12. If a regulation of this license contract is void by law, the validity of the remaining regulations is not affected. If there is such a regulation it will be replaced by a valid, according to the legal regulations and enforceable regulation with similar intention and similar economic consequence.
13. The license contract is effective by delivery of the software of the licensor to the licensee and/or by usage of the software by the licensee. This license contract is also valid without licensor's signature.
14. The license automatically goes out if the licensee does not agree to the license regulations described here or offend against the license regulations of this license contract. With ending the license contract the licensee is obliged to extinguish or to destroy the software and all copies of it no matter if installed or stored on disk or to hand all of it back to Telemotive AG.
15. The licensee is liable for all damages caused to the licensor by the violation of these license regulations.

2 PRODUCT LIABILITY

For all offers, sales and supplies the following conditions apply exclusively, even if the buyer, orderer and suchlike prescribes other conditions. Alterations are only valid, if they are agreed in writing.

1. The technical documentation is part of the products. The product liability and the product guarantee will be excluded, if contents and in particular the safety references and instructions of the documentation are not considered.
2. The products do belong to the group of test tools. By application of the equipment a disturbance of the tested system cannot be completely excluded. For this reason, the warranty of a perfectly functioning system cannot be taken over by the manufacturer. Application of the product takes place at one's own risk.
3. The liability of the substitution of damages according to §1 product liability law is expressly excluded in the context of §9 product liability law, as far as compelling legal terms do not provide anything else.
4. In no event will the producer be liable for any indirect, incidental, special or consequential damages, including loss of profits, loss of revenues, loss of data, loss of use, any other economic advantage or damage caused by pretensions of third party towards the customer out of this agreement, under any theory of liability, whether in an action in contract, strict liability, tort (including negligence) or other legal or equitable theory.
5. The burden of proof is with the customer.
6. The Telemotive AG does ensure the legal warranty according to German law. Except for warranties expressly set forth in this agreement, any and all products are delivered "as is" and the producer makes and the customer receives no additional express or implied warranties. The producer hereby expressly disclaims any and all other warranties of any kind or nature concerning the products, whether express or implied, including without limitation, any warranty of title, merchantability, quality, accuracy or fitness for a particular purpose or the customer's purpose. The producer expressly disclaims any warranties that may be implied from usage of trade, course of dealing or course of performance. Except for the express warranties stated in this agreement the products are provided with all faults and the entire risk of unsatisfactory quality, performance, accuracy. The possible effort is with the customer. The producer does not warrant that the products will operate without interruption or be error free.
7. The Telemotive AG is justified to exchange defective goods against homogeneous acceptable ones or to eliminate the fault within an appropriate period. In this case a demand for redhibitory action or reduction of price expires. Warranty claims presuppose a due notice of defects.
8. Resale, transfer, donation, exchanges or the rental of the offered products at third party is permitted without clearance of the Telemotive AG.
9. German Law is deemed to be as legal basis.

3 Overview

This user guide describes the administration of the **Remote Control Touch**, the surface of the installed software and its operation.

The configuration of the Remote Control Touch was only tested with Microsoft® Windows® 7.

This document refers to **blue PiraT Mini** firmware version 02.03.01 and the **Telemotive System Client** version 2.3.1. Some features depend on model and feature license or may not be available in older versions.

Software updates and user guides for other, optional, licensed enhancements are available in the Telemotive ServiceCenter. (*You will find the address under Contact*).

To ensure the most reliable operation of your system as possible, please make sure to use always current firmware and software versions.

[Index](#)

4 System requirements

Control Unit

A Laptop or a PC is used to configure the devices by a software client. It also allows to save the recorded data and to use them offline.

blue PiraT2 / blue PiraT Mini

The **blue PiraT Mini** is the newest and very small datalogger which was developed by Telemotive AG. The **blue PiraT2** is his preceding model with enhanced features.

The communication of bus systems and control units are monitored and relevant data can be recorded very precisely with the data loggers of the Telemotive AG. The collected data are stored on the data logger and can be downloaded via Ethernet and, e.g., analyzed on a test computer.

Telemotive System Client

The software client is needed to configure the device and later to download or convert the recorded data.

4.1 Further manuals

Beside this user guide the Telemotive AG offers the main manuals for the client as well as for the different data logger generations in its ServiceCenter at <https://sc.telemotive.de/bluepirat>.

User manual for the Telemotive System Client

https://sc.telemotive.de/4/uploads/media/TelemotiveSystemClient_UserManual.pdf

User manual for blue PiraT2 / blue PiraT2 5E

https://www.telemotive.de/4/uploads/media/blue_PiraT2_UserManual.pdf

User manual for blue PiraT Mini

https://www.telemotive.de/4/uploads/media/blue_PiraT_Mini_UserManual.pdf

Licensed enhancements have own manuals which are stored in the ServiceCenter too. You will find a list of these enhancements in the user manuals in the chapter **Additional features by optional licenses**.

[Index](#)

5 Remote Control Touch

This chapter describes the position and function of the Remote Control Touch components, the Remote Control Touch accessories and the installation of hard- and software.

The Remote Control Touch is the remote control and external display device for the blue PiraT Mini and blue PiraT2 data loggers or a TSL network.

The Remote Control Touch allows you to:

- display bus load, status and memory of available interfaces,
- display date and time,
- trigger functionkeys,
- display set markers,
- adjust backlight and volume,
- set triggers,
- record and play voice notes.

Familiarize yourself with its components to operate the Remote Control Touch correctly.

5.1 Position of components

5.1.1 Top view




Figure 5.1: Top view with components

[Index](#)

5.1.2 Side view, from the right




Figure 5.2: Side view, from the right with components

5.1.3 Rear side



Figure 5.3: Rear side view with components

[Index](#)

5.2 Functionality of components

Functionality of the components is impaired by certain conditions such as moisture, darkness, heat or cold, mechanical action, dirt or similar. Observe therefore the points described in chapter 8 Maintenance provisions and safety regulations.

5.2.1 Ports

The ports are used to connect the Remote Control Touch, for example with the power supply (see section 5.4.1).

Port		Cable	Connection with ...
No.	Designation		
1	8-pol LEMO socket	Power cable with LEMO connector to banana plug	Power source
2 3	Gbit Ethernet (RJ45)	Gbit Ethernet cable	Client computer or data logger
4	Mini USB 2.0	Micro USB connecting cable	USB devices
5	4-pol audio jack plug stereo out/microphone (3.5 mm) OMTP	3.5" jack/audio cable	Microphone, speaker, headset, etc.

Table 5.1: Available connections

5.2.2 Brightness sensor

The brightness sensor helps adjust the screen's backlight depending on the ambient light. It serves only the automatic regulation and is permanently active.

5.2.3 Home button

The Home button is used to:

- switch the device on or off,
- wake up the device from sleep mode,
- reset the device to default settings and
- switch between applications.

5.2.4 Speaker

The speaker is used to play voice notes. Its volume is adjustable.

[Index](#)

5.2.5 LEDs

Activity and operating state of the Remote Control Touch are indicated by the LEDs.

Activity / operating state	Behavior	
	Active LED	State LED
device goes to standby	green pulsing	not lighted
in error mode	green light	red light
in operation	green light	not lighted
powered off	not lighted	not lighted
press Home button	brief light-up	not lighted
record voice note	brief light-up	red pulsing, four times, then not lighted
reset device	green light	red flashing, two times, then not lighted
set trigger	brief light-up	not lighted
switch off device	green pulsing	not lighted
switch on device	green flashing	not lighted
update firmware	green light	red light
wake up device	brief light-up	brief light-up

Table 5.2: LED behavior

5.2.6 Microphone

The microphone is used to record voice notes on triggers. The voice recording is audible up to a vehicle speed of 130 km/h.

5.2.7 Touchscreen

The screen is used to operate the Remote Control Touch. Only use the tip of the finger to operate it. The brightness is adjustable.

5.3 Accessories

The Remote Control Touch is supplied with an Ethernet cable (length: ~ 6 m) and a power cable with LEMO connector to banana plug (length: ~ 6 m).

Additional accessories are available for purchase. The following accessories are compatible with the Remote Control Touch:

- mounting bracket
- various adapter cables

Please contact our sales department for more information about the accessories. The relevant manuals for these enhancements can be found in the Telemotive ServiceCenter.

5.4 Installation

The Remote Control Touch requires a connection to the power supply and one to the client computer. Then the Remote Control Touch can be used in standalone mode.

In order to make full use of all functions of the Remote Control Touch, a connection to at least one blue PiraT data logger is required. This creates a Telemotive **System Link (TSL)**.

Find more information about client and TSL in the **User manual for the Telemotive System Client**.

5.4.1 Cable connection

Note:

Connect the Remote Control Touch only with devices of Telemotive AG (blue PiraT, Remote Control).


5.4.1.1 With power supply

Note:

Make sure that the Remote Control Touch is switched off before connecting it with a power supply or disconnecting it.

The power connection of the Remote Control Touch is similar to that of the Remote Control Voice. They are NOT identical. We therefore recommend to use the device-specific cable.

A power cable with LEMO connector to banana plug is required for the connection of the Remote Control Touch to the power supply.



Length: ~ 600cm

Figure 5.4: Power cable with LEMO connector to banana plug

Plug the LEMO connector into the Remote Control Touch and the banana plug into the power supply (**red/Vbat /+ /Clamp 30** and **black/GND/- /Clamp 31**).

5.4.1.2 In the network

The Remote Control Touch has two Ethernet ports. The loggers to be controlled are connected directly via Ethernet to the Remote Control Touch. These loggers must establish a TSL network

with the Remote Control Touch in order for the Remote Control Touch to recognize them. The client computer can be connected to a free Ethernet port of the TSL chain.



Figure 5.5: TSL network with one bPMini, one Remote Control Touch and one bP2 (e.g.)

[Index](#)

5.4.2 Telemotive System Client

Note: When delivered, the Remote Control Touch is configured as a DHCP server.

Open your internet browser.

Enter the IP address of the Remote Control Touch in the address bar. (IP factory setting: 192.168.0.233)

Press the **[Enter]** key.

- The computer connects to the device.
- The TSL Client Portal opens.




Figure 5.6: TSL Client Portal

Note:

Your network connection must be set to “Obtain IP address automatically”.

Click **[Download]**, to download the Telemotive System Client directly from the device.

Follow these steps, depending on your browser:

Browser	Proceeding
Internet Explorer	Click [Save] , to locally save the file on your system. Click [Accomplish] .
Mozilla Firefox	Click [Save file] , to locally save the file on your system. Click the arrow on the right top of the browser menu and select the downloaded application in the appearing context menu.

In the dialog that opens select the desired software language from the dropdown menu.
Click **[OK]**.

Follow the instructions in the next dialog and select an installation directory.
Click **[Install]**.

- Telemotive System Client is installed.
- Shortcut to “Telemotive System Client” appears on the desktop and in the start menu.



Figure 5.7: Shortcut to Telemotive System Client

[Index](#)

5.5 Connecting the Remote Control Touch with a data logger

5.5.1 Configure the network settings

The Remote Control Touch and a data logger are configured as **DHCP-Server** by default. They both got the **IP address 192.168.0.233**. There are three different ways to connect this two devices.

1. Set up the data logger as DHCP-Server and the RCT as DHCP-Client
2. Set up the data logger as DHCP-Client and the RCT as DHCP-Server
3. Set up both devices as DHCP-Client

You can read in the **Telemotive System Client manual (Network settings)** how to set up the network settings. You can find the manual in the Client under **[Help]**.




Figure 5.8: Opening the Telemotive System Client manual

In our example we configured the Remote Control Touch as DHCP-Client and connected it with the data logger (**see chapter 5.4.1.2**). In the next picture you can see the two devices in the client. The device with the IP address 192.168.0.233 is the data logger, because it is set up as DHCP-Server. In the **Telemotive System Client manual (Name)** you can see how to give names for the devices. This might be helpful for better clarity.




Figure 5.9: Viewing the devices in the client

5.5.2 Activating Telemotive System Link (TSL)

To use the RCT, you have to activate TSL at **both** devices. You can activate it by clicking [**TSL active**] like you can see in the following picture. In the **Telemotive System Client manual (Establishing and configuring a TSL network)** you can find more details about TSL.




Figure 5.10: Activating TSL

If TSL is active at both devices, they are shown as TSL compound in the client. You can use the RCT with the data logger now.




Figure 5.11: Representation of the TSL compound in the client

5.6 Resetting the network settings

Note:

Due to a wrong network setting it may be impossible to reach the data logger any more. In this case the network configuration can be resetted by a long press on the [ON / Trigger] button to default settings: => DHCP server with IP 192.168.0.233.

Switch off the device

Press the home button.

- Active-LED and State-LED are blinking once. Active-LED is blinking green.

Press and hold the home button for about 20 sec. until the state LED is blinking 2 times.

- State-LED is blinking 2 times
- Active-LED is lightning green.
- Remote Control Touch loads the default configuration.

Tipp on **[Accept]**.

- The warning popup disappears.
- Active-LED is blinking green.
- The display shows the launcher with a progress bar.
- A warning popup is shown.

Tipp on **[Accept]**.

- The warning popup disappears.

The Remote Control Touch is ready when:

- The view **[Overview]** is shown on the display and
- Active-LED is lightning green.

Afterwards the data logger can be reached again by using a direct connection with a PC/Laptop.

You'll find more information in the **Telemotive System Client** manual

[Index](#)

6 Surface

This chapter describes the application setup and the layout of the individual views as well as the displays contained.

The Remote Control Touch software is very user-friendly thanks to its graphic surface and the clear outline.

Figure 6.1 shows the outline of the application in <Home> view and four applications. The application views contain minimum one tab. For the applications Driver View and Settings, the number and naming of the tabs is set.




Figure 6.1: Application sitemap

Note: “n” stands for any number of devices

When an application is launched for the first time after switching on, the uppermost tab is shown. The next time you launch the application, the tab last opened is shown, except for the application Busload.

[Index](#)

6.1 Layout of the views

All views consist of a window and a dark blue frame.

As the window contents vary depending on the view, they are described in more detail in the following sections of this chapter.

The dark blue frame contains in all views a header bar on top and, with the exception of the <Home> view, a tab bar at the bottom.




Figure 6.2: Components of the application views

6.1.1 Header bar

In each view the header bar contains:



- the designation of the current view and



- date and time of the device or the TSL network.



Depending on the operating mode, two representations are possible in the top left corner of the <Home> view:

1. If you operate the device in standalone mode, the Telemotive logo  and the device name are shown.
2. If you operate the device in the TSL network, the TSL logo  and the TSL name are shown.

[Index](#)

In the application views, the header bar contains on the left:

- the button  respectively  for the side menu,
- the icon of the current application (see section 6.2) and



- the device name in standalone mode or
“TSL: *name of the TSL* (*number of TSL members*)” in the TSL network.



6.1.2 Tab bar

In the application views, the tab bar contains minimum one tab. The tabs serve as shortcuts to the individual tab sheets. Inactive tabs contain the name of the tab sheet in blue letters, active tabs in white and bold. The active tab is further characterized by a narrow bright yellow margin above.



6.2 Applications

An icon has been set for each of the four applications to find them more easily. In the <Home> view and the side menu these icons serve as shortcuts to the applications and on the tab sheets they serve for orientation.

Icon	Name	Function
	Status	Display of information on the connected devices
	Driver View	Management of the functionkeys, markers and voice notes
	Busload	Display of all available buses and their channels
	Settings	Adjustment of backlight and volume of the Remote Control Touch

Table 6.1: Application overview





Figure 6.3: Home view

6.3 Tab sheets

In the applications  Driver View and  Settings, the number and naming of the tab sheets is set.

The application  Busload contains one tab sheet for each available interface of the connected loggers, with the exception of **[GPS]** and **[MOST150]**. The tab sheets are named after the respective bus interface.
If multiple loggers with active GPS resp. MOST150 are connected, each GPS resp. MOST interface is assigned a tab sheet.


The application  Status contains minimum two tab sheets:

- the tab sheet **[Overview]** and
- the tab sheet of the Remote Control Touch with the name assigned in the Telemotive System Client.

If more devices in a TSL network are cable-connected with the Remote Control Touch, each device is assigned a tab sheet named after it.

6.3.1 Overview

The window of the tab sheet **[Overview]** contains, apart from the trigger counter at <Trigger Count>, a tabular overview of all connected devices and the Remote Control Touch with the following displays:



Logger	IP	Status	Type	FW
RCTouch_4760	10.64.76.180	OK	RC Touch	02.03.01
DUT_178_Martin	10.64.76.50	OK	bP Mini	02.03.01

Trigger Count: 12

Device name IP address Device status Device type Firmware version

Overview RCTouch_4760 DUT_178_Martin

Figure 6.4: Tab sheet “Overview”

[Index](#)

6.3.2 *Device name n*

Note: “n” stands for any number of devices

Each device listed on the tab sheet **[Overview]** can be viewed separately on the respectively named tab sheet.

The window of these tab sheets, with the exception of the Remote Control Touch window, contains the following displays:

Logger:	1 bp2-Jenny	Config:	2 default
Network:	3 IP 10.64.76.187 Subnet 255.255.240.0	4 DHCP Client	5 Terminal-IP 10.1.124.63 Subnet 255.255.0.0
Memory:	6 78 GB	7 0% filled	8 0% protected
Status:	9 ERROR	Count:	10 4

- 1 Device name
- 2 Configuration name
- 3 IP address and subnet mask
- 4 DHCP mode
- 5 Terminal IP address and subnet mask
- 6 Storage capacity
- 7 Memory percentage filled
- 8 Memory percentage protected
- 9 Device status
- 10 Error count

Figure 6.5: Tab sheet “*Device name n*”

Note:


The Remote Control Touch has no internal memory. The memory percentage filled and protected are therefore not shown on its tab sheet.

6.3.3 Functionkeys

The window of the tab sheet **[Functionkeys]** contains two buttons on the left and ten functionkeys on the right. The functionkeys can be assigned “complex triggers” (see **User manual for the Telemotive System Client**). The name of the complex trigger is shown as text on the key.

Figure 6.6: Tab sheet “Functionkeys”

6.3.4 Markerlist

The window of the tab sheet **[Markerlist]** contains two buttons on the left and a list of set markers on the right. The markers are sorted by index and indicate date and time of the setting. A trigger that was set using the **[Record]** button contains a voice note. This is indicated by the  button in the marker entry.





Figure 6.7: Tab sheet “Markerlist”

6.3.5 CAN/Serial/LIN/Ethernet/Camera/CCP_XCP

Each of these tab sheets contains a tabular overview of all channels of the respective bus with the following displays (here using the example of the tab sheet **[CAN]**):



The screenshot shows the 'Busload' tab sheet for the CAN bus. It displays a table with three columns: 'Id', 'Name', and 'Busload'. The table lists four channels, all with a busload of 0%. Yellow boxes highlight the table columns, and yellow lines point from labels below to the 'Id', 'Name', and 'Busload' columns.

Id	Name	Busload
#1	HSCAN-1	0 %
#2	HSCAN-2	0 %
#3	HSCAN-3	0 %
#4	HSCAN-4	0 %

Figure 6.8: Tab sheet “CAN”

[Index](#)

6.3.6 MOST150

Each connected logger that receives MOST150 messages generates its own tab sheet **[MOST150]** with the following displays:




Figure 6.9: Tab sheet "MOST150"

If the window contains only the display of "Light off", the cable is incorrectly connected or no MOST data is sent and the bus is inactive.





Figure 6.10: Tab sheet "MOST150": Light off

6.3.7 GPS

Each connected logger that receives GPS data generates its own tab sheet **[GPS]** with the following displays:




TSL: Touch-Most-Most (2) Busload		21.10.2015 - 10:16:48	
Latitude:	48° 11' 14" N	Latitude	
Longitude:	011° 35' 11" E	Longitude	
Altitude:	605.8 M	Altitude above sea level	
Course:	276.8°	Course/direction	
Speed:	0.0 km/h	Speed	

CAN Serial FlexRay LIN Ethernet Camera MOST150 **GPS**

Figure 6.11: Tab sheet “GPS”

[Index](#)




TSL: Touch-Most-Most (2) Busload		21.10.2015 - 10:17:56	
Longitude:	011° 35' 11" E	Longitude	
Altitude:	605.2 M	Altitude above sea level	
Course:	276.8°	Course/direction	
Speed:	0.0 km/h	Speed	
Satellites:	03	No. of satellites found	

CAN Serial FlexRay LIN Ethernet Camera MOST150 **GPS**

Figure 6.12: Tab sheet “GPS” – continuation

If the window contains only the display of “No GPS signal”, this may be for at least one of the following reasons:

- The GPS connection is disabled.
- The GPS receiver is not connected.
- No satellite or too few satellites were found (minimum 3).







TSL: Touch-Most-Most (2) Busload		21.10.2015 - 09:57:40	
No GPS signal			

Figure 6.13: Tab sheet “GPS”: No GPS signal

6.3.8 General

The window of the tab sheet **[General]** contains a total of five control elements:

1. Brightness scale with brightness slider	
2. ON/OFF button	
3. Volume scale with volume slider	
4. and 5. Intern/Extern button	

To adjust a button, tap on the button or in the gray boundary.
To adjust a slider, swipe it to or tap on the desired position on the brightness scale.

More information on the operation is provided in chapter 7.

Refer to the following table for the meaning of the individual control elements.

Operating element	Meaning
Brightness scale with brightness slider	Depending on the position of the slider on the scale, if the [OFF] button is visible, the backlight is: <ul style="list-style-type: none"> • dimmed (left) or • intensified (right).
[ON] button	Brightness is automatically adjusted. Brightness scale with brightness slider is inactive.
[OFF] button	Brightness is adjusted according to the position of the brightness slider on the brightness scale. Brightness scale with brightness slider is active.
Volume scale with volume slider	Depending on the position of the slider on the scale, the volume is: <ul style="list-style-type: none"> • decreased (left) or • increased (right).
[Intern] button	Remote Control Touch internal hardware is actuated. Acoustic signals are played back through the speaker and recorded through the microphone (see section 5.1.1).
[Extern] button	External hardware of the connected accessories is actuated.

Table 6.2: Operating elements of the tab sheet “General”

Note:
The quality of playback and recording acoustic signals depends on the actuated hardware.

6.4 Displays

The displays of the Remote Control Touch are similar to those of the data loggers. An overview to their meanings is provided in the following table. You can find the view that contains the display via the cross reference in the column "See".


Display	Meaning	See
Bus load	indicates the degree with which the bus is busy with data transfer	6.3.5 6.3.6
DHCP mode	can be configured under General → Network settings indicates whether the device functions as a server or a client or whether DHCP was disabled	6.3.2
Error count	indicates the number of active errors (can be viewed in the bug reporter) when the status is ERROR or WARNING	6.3.2
Device name	can be configured under General → Name provides orientation in the application and is part of the trace file's file name	6.1.1 6.3.1 6.3.2
Device status	see Table 6.4: Device status messages	6.3.1 6.3.2
Device type	see Table 6.5: Device types	6.3.1
Memory percentage protected	can be configured under General → Buffer indicates the percentage of the memory capacity that is protected	6.3.2
IP address	indicates the IP address of the device	6.3.1 6.3.2
Channel name	can be configured under *Bus* → *Bus #...* → Name provides orientation in the application and is part of the trace file's file name	6.3.5
Channel number	serves as index for sorting the channel lists is obtained from the configuration in the Telemotive System Client	6.3.5
Configuration name	can be configured under General → Name indicates the name of the configuration on the device	6.3.2
Logger name	can be configured under General → Name helps mapping logger-specific tabs	6.3.6
Markerlist	contains the markers of the set triggers sorted by index Each marker is specified by the time (date and time) the trigger was set. The  button is used to play the voice note.	6.3.4
Message category	see Table 6.6: Message categories	6.3.6
Storage capacity	depends on the internal memory Since the Remote Control Touch does not have internal memory, the tab shows "0 GB".	6.3.2
Subnet mask	indicates the subnet mask of the connected device	6.3.2
Memory percentage filled	indicates the percentage of the memory capacity that is filled	6.3.2

Table 6.3: Displays overview

The device status may display the following messages:

Message	Form	Meaning	Data recording
ERROR	red flashing	device in error mode	jeopardized
FWUPDATE	dark blue flashing	logger firmware is updated	stopped
MEMORY	dark blue flashing	lack of memory capacity	jeopardized
OK	dark blue	normal operation	normal
RING	dark blue flashing	logger in ring buffer mode	normal
WARNING	dark blue flashing	jeopardized operation	normal

Table 6.4: Device status messages

More information on the device status is provided in the user guides of the data loggers, section 10.5 Memory space and level.

The following types of devices exist:

Message	Type
RCTouch	Remote Control Touch
BP Mini	blue PiraT Mini
BP2 MB1.x	blue PiraT2
BP2 MB2.x	blue PiraT2 5E

Table 6.5: Device types

In MOST150 the following categories of messages exist:

Category	Meaning						
Control	Control data; for the passing of control messages; transmits up to 384 data byte						
MDP	MOST Data Packet; transmits up to 1524 data byte						
MEP	MOST Ethernet Packet; for the passing of Ethernet messages; transmits up to 1506 data byte						
Streaming Channel/Channels	Synchronous data range; transmits up to 372 data byte						
	<table border="1"> <thead> <tr> <th>Channel</th> <th>Busload/Size</th> <th>Messages</th> </tr> </thead> <tbody> <tr> <td>*Number of streaming channels* Streaming Channels</td> <td>*Bus load in bytes* B</td> <td>(remains empty)</td> </tr> </tbody> </table>	Channel	Busload/Size	Messages	*Number of streaming channels* Streaming Channels	*Bus load in bytes* B	(remains empty)
	Channel	Busload/Size	Messages				
Number of streaming channels Streaming Channels	*Bus load in bytes* B	(remains empty)					
With only one streaming channel, the display under "Channel" is restricted to "Streaming Channel".							

Table 6.6: Message categories

6.5 Other views

Other views include:

- views that appear due to the configuration of a connected logger,
- views that can only be closed via the Remote Control Touch and/or
- views that appear outside the application.

6.5.1 AlertDialog

Precondition	none
Timing	Internal communication has failed.
Options	close popup

To close the popup, tap on **[OK]**. Then repeat the last command.

6.5.2 FW-Update

Precondition	none
Timing	Remote Control Touch firmware is updated.
Options	none




Figure 6.14: FW-Update view

[Index](#)

6.5.3 Launcher

Precondition	none
Timing	Remote Control Touch is switched on. (before the application)
Options	close popup




Figure 6.15: Launcher view

Within the view “Launcher” a safety message in a popup appears after a short time (see section 8.3).

To close the popup and use the application, tap on **[Accept]**.




Figure 6.16: Popup in Launcher view

[Index](#)

6.5.4 RC Monitor

Precondition	Optional Remote Control Monitor license is installed. An application is open.
Timing	Complex trigger configured to the <Action> [Display Remote Control Monitor] is actuated. (see section 7.11)
Options	set trigger, close view

The view is constantly updated and depends on the configuration in the Telemotive System Client.

More information on this feature is provided in the **Remote Control Monitor** user guide.

To close the view, press the Home button or tap on **[Close]**.




Figure 6.17: Window “RC Monitor”

6.5.5 RC Text

Precondition	An application is open.
Timing	Complex trigger configured to the <Action> [Display notification on Remote Control] is actuated. (see section 7.11)
Options	set trigger, close view

The view is not updated and depends on the configuration in the Telemotive System Client.

To close the view, press the Home button or tap on **[Close]**.




Figure 6.18: Window "RC Text"

6.5.6 Standby

Precondition	none
Timing	Remote Control Touch is switched off or not used for an extended period. (after the application)
Options	none








Figure 6.19: Standby view

To exit the standby mode, press the Home button or tap on the screen.

6.6 Restrictions in standalone mode

6.6.1 Remote Control Touch applications

In standalone mode the Remote Control Touch is not connected to any data logger. Some functions are therefore not available.

- The application  Status remains unaffected.
- The application  Busload is inactive.
- The application  Driver View is inactive.
- The application  Settings remains unaffected.

[Index](#)

6.6.2 Telemotive System Client applications

The Telemotive System Client also provides less functionality than for a device integrated in the TSL network.

In the TSL network all six applications are available via the connected data logger(s):

1. Online Monitor
2. Download data
3. Convert data
4. Open configuration
5. Update firmware
6. Open bug report




Figure 6.20: Tab “Network Logger” in the TSL network

Find more information about the Telemotive System Client applications in a TSL network in the **User manual for the Telemotive System Client**, chapter 9.

In standalone mode the following applications are available:

4. Open configuration
5. Update firmware
6. Open bug report




Figure 6.21: Tab “Network Logger” in standalone mode

The applications **[Update firmware] (5)** and **[Open bug report] (6)** provide the same functional range in both modes. Find the applications descriptions in the **User manual for the Telemotive System Client**, chapters 15 and 16.

The application **[Open configuration] (4)** provides less categories in the configuration tree (e.g., **[General]**) and less sub-items (e.g., **[Name]**) than for a device integrated in the TSL network.

[Index](#)




Figure 6.22: Configuration trees: Standalone mode (left) – TSL (right)

Find more information about components of the configuration tree in the **User manual for the Telemotive System Client**, chapters 8 and 11.

[Index](#)

7 Operation

Important:

Only use the tip of the finger to operate the Remote Control Touch.

This chapter describes instructions that are possible using the Remote Control Touch.

Functionality of the components is impaired by certain conditions such as moisture, darkness, heat or cold, mechanical action, dirt or similar. Observe therefore the points described in chapter 8 Maintenance provisions and safety regulations.

7.1 Actuating functionkey

Navigate to the tab sheet **[Functionkeys]** in the application  Driver View.

Tap on the desired functionkey that was previously assigned with a “complex trigger”, see section 7.11.

- The Remote Control Touch responds according to the <Action> that was set in the configuration for the <Event> **[Key Stroke]** using a functionkey as <Key>.

[Index](#)

7.2 Adjusting backlight

Navigate to the tab sheet **[General]** in the application  Settings.

7.2.1 Automatic adjustment

If you want the brightness of the screen to adjust automatically, tap on the gray **[OFF]** button under <Auto Brightness>.

- Brightness is automatically adjusted.
- The blue **[ON]** button is active.
- Brightness scale with brightness slider is inactive.

7.2.2 Manual adjustment

If you want to adjust the brightness of the screen manually, tap on the blue **[ON]** button under <Auto Brightness>.

- The gray **[OFF]** button is active.
- Brightness scale with brightness slider is active.

Swipe the brightness slider to the desired position or tap on the desired position on the brightness scale.

- Brightness is set according to adjustment.
- A brief fade-in indicates the new brightness value set in percent.




Figure 7.1: Fade-in after adjusting the brightness

7.3 Adjusting volume

Note:

A tone is produced to simulate the newly set volume. If you set the volume to “Volume: 0%”, the Remote Control Touch is mute. Its acoustic signals are inaudible.

Navigate to the tab sheet **[General]** in the application  Settings.

Swipe the volume slider to the desired position or tap on the desired position on the volume scale.

- A change in volume is indicated by a tone and at the same time it simulates the newly set volume.
- A brief fade-in indicates the new volume value set in percent.




Figure 7.2: Fade-in after adjusting the volume

[Index](#)

7.4 Changing application

To reach another application, you have two options:

1. Press the Home button ...
 - Active LED lights up briefly.
 - <Home> view appears.
2. Open the side menu (see section 7.6) ...

and tap on the icon of the desired application.


7.5 Changing tab sheet

To reach other tab sheets within an application, tap in the tab bar on the tab of the desired tab sheet.


- Selected tab sheet appears.

To reach tab sheets in other applications, switch to the application of the desired tab sheet first (see section 7.4) and continue to proceed as just described.

7.6 Opening and closing side menu



To open the side menu, you have two options:

1. Tap on the  button.
2. Swipe from the left edge of the screen to the right.

To close the side menu, you have three options:


1. Tap in the window of the tab sheet.
2. Tap on the  button.
3. Swipe from the right to the left edge of the screen.

Figure 7.3: Example side menu

[Index](#)

7.7 Playing voice note

Note:

If you do not hear an acoustic signal, increase the volume (see section 7.3).

The quality of the recording and playback is dependent on the <Speaker> and <Microphone> settings on the tab sheet [General] (see section 6.3.8).

Navigate to the tab sheet [Markerlist] in the application  Driver View.

Tap on the  button in the marker entry.

- Voice note of the marker is played.
- The following duration display complements the marker entry.






Figure 7.4: Voice note duration display

If you tap on a second  button while the voice note is played, the playback is stopped and the second voice note is played.


If you want to stop playing the voice note prematurely, tap on the  button again.

The duration display disappears when the playback of the voice note has ended.

7.8 Scrolling through applications

If the application contains more than one tab sheet, you have the option to scroll.

Note:

In the application  **Driver View**, there is a risk of setting unwanted triggers when scrolling through. You should therefore use the tab bar to change the tab sheet.

Swipe the tab sheet horizontally:

- to the left The tab sheet adjacent to the right appears.
- to the right The tab sheet adjacent to the left appears.

If there is no tab sheet adjacent to the left or right, this is indicated by a gray margin on the left respectively right edge of the screen.

[Index](#)

7.9 Scrolling through tab bar

If the tabs exceed the width of the tab bar, you have the option to scroll.

Swipe the tab buttons horizontally:

- to the left Tabs adjacent to the right appear.
- to the right Tabs adjacent to the left appear.

If there is no tab adjacent to the left or right, the tab bar turns gray on the left respectively right edge of the screen.

7.10 Scrolling through tab sheet

If the window exceeds the height of the tab sheet, you have the option to scroll.

Swipe the tab sheet vertically:

- upwards Window is scrolled down.
- downwards Window is scrolled up.

If the window reached the very top or bottom, this is indicated by a gray margin on the top respectively bottom of the screen.

7.11 Setting and deleting complex triggers

Find more information on complex triggers in the **User manual for the Telemotive System Client**, section 8.13.

Launch the Telemotive System Client by double-clicking the shortcut “Telemotive System Client” on the desktop or in the start menu.

Select the desired TSL in the window <Network Logger>.

- Selected line is highlighted blue.

Click on the application  **[Open configuration]**.

- The tab <Configuration> opens with the configuration tree on the left.

Click the **[+]** button in front of the folder **[Trigger – Device: *Logger name*]** in the configuration tree or double-click on the folder itself.

- Trigger folder is expanded.

[Index](#)




Figure 7.5: Expanding trigger folder

Note:

Triggers are configured per device. Events only trigger actions on the source device. TSL-wide events are not supported.

Double-click on **[Add Trigger... (...)]**.

- New trigger is generated and displayed in the configuration tree (e.g., Trigger #1).
- The window <Trigger> opens.

Note:

If the trigger configuration is not complete, this is indicated by a red symbol with exclamation mark at the trigger in the configuration tree and at the affected areas in the window <Trigger>.




Figure 7.6: Notice message for missing settings

[Index](#)

Enable the checkbox **Trigger active**.
Select the desired <Trigger Mode>.
Enter a name for the trigger in the <Name> field.
Select the desired <Event> from the dropdown menu.
Edit the event-specific settings.
Select the desired <Action> from the dropdown menu.

Note:

It is possible to create more than one trigger with the same <Event>. However, their <Action>s must not be mutually exclusive. This would be the case if [Display ...] were configured at least twice. If you clicked on [Write to logger], in this case a popup with an error message would appear.




Figure 7.7: Error message due to unauthorized configuration

Edit the action-specific settings.
Click on **[Write to logger]**.

- Configuration is transferred to the logger.

Note:

If you select [Key Stroke] as the <Event> using a functionkey as <Key>, the trigger appears on the tab sheet [Functionkeys] on the selected functionkey with the specified name for the trigger.

If you assign more than one trigger to a functionkey, up to two triggers are displayed. Beyond that, the display is limited to [MULTIACTION].




Figure 7.8: Functionkeys with complex triggers

To delete a complex trigger, you have two options:

1. Click on the [Remove trigger] button in the window <Trigger> ...
2. Open the context menu of the trigger to be deleted with a right-click. Click on [Delete Trigger] ...




Figure 7.9: Context menu of a trigger

and click on [Write to logger].


- Configuration is transferred to the logger.
- Trigger is deleted and disappears from the configuration tree.

Note:

If you delete a trigger that is actuated by the <Event> [Key stroke] with a functionkey as <Key>, it disappears from the tab sheet [Functionkeys].

[Index](#)

7.12 Setting triggers

Navigate to a tab sheet in the application  Driver View.

7.12.1 Trigger with voice note

Note:

The quality of the recording and playback is dependent on the settings of <Speaker> and <Microphone> on the tab sheet [General] (see section 6.3.8).

Tap on [Record] to set a trigger with voice note on the connected devices.

- Sound recording starts. Recording length is indicated on the button with “Recording... ellapsed time: *Hour*:*Minute*:*Second*”.
- A fade-in tells you under which index and timing (date and time) the trigger was set.
- Marker appears on the tab sheet [Markerlist].





Figure 7.10: Voice note recording starts

To stop the recording, tap on [Record] again or wait until the <Max. recording length> configured in the Telemotive System Client elapses.

- Two brief fade-ins appear one after the other:
 - “Stopped recording!” Sound recording is stopped.
 - “Uploaded record!” Sound recording is uploaded.
-  button appears in the Marker entry.




Figure 7.11: Voice note recording stops

[Index](#)

7.12.2 Trigger without voice note

Note:

Setting a trigger without voice note is confirmed acoustically. If you do not hear an acoustic signal, increase the volume (see section 7.3).

Tap on **[Trigger]** to set a trigger on the connected devices.

- A tone sequence indicates that a marker was set.
- A brief fade-in tells you under which index and timing (date and time) the trigger was set.
- Marker appears on the tab sheet **[Markerlist]**.




Figure 7.12: Marker set

7.13 Switching the device off

Press and hold the Home button until the Active LED pulses green.

- Active LED pulses green.
- View “Standby” appears on the screen.

The Remote Control Touch is switched off when:

- the view “Standby” disappears and
- the Active LED goes out.

[Index](#)

7.14 Switching the device on

Press the Home button.

- Active LED and State LED light up briefly. Active LED then flashes green.
- View “Launcher” with advancing progress bar appears on the screen.
- Popup with warning appears.

Tap on **[Accept]**.

- Popup with warning disappears.

The Remote Control Touch is switched on when:

- the tab sheet **[Overview]** appears and
- the Active LED lights green.

7.15 Updating firmware

Find more information on firmware update in the **User manual for the Telemotive System Client**, chapter 15.

Note:

**Only update the Remote Control Touch firmware with the vehicle at standstill.
In the TSL network, the data logger does not record any data during the update.**

Launch the Telemotive System Client by double-clicking the shortcut “Telemotive System Client” on the desktop or in the start menu.

Select the Remote Control Touch in the window <Network Logger>.

- Selected line is highlighted blue.

Click on the application  **[Update firmware]**.

- The tab <Firmware- / Licenses update> opens.




Figure 7.13: Tab “Firmware- / Licenses update”

Note:

If you operate the device in the TSL network, apply the following steps on all TSL members.

Under <New firmware> click on **[Open]**.

- Dialog opens.

[Index](#)

Select the desired firmware.

Click on **[Open]**.

Note:

For the Remote Control Touch you need the same firmware as for the blue PiraT Mini.




Figure 7.14: Opening firmware-packet

- Selected firmware appears in the display field.



Figure 7.15: Valid firmware-packet

Note:

If you select an invalid firmware-packet, the following notice message appears and the [Update firmware...] button remains inactive.




Figure 7.16: Notice message for invalid firmware-packet

Click on [Update firmware...].

- Firmware file is verified.
- Dialog opens.

[Index](#)




Figure 7.17: Notice message before firmware update

Follow the dialog instructions.

Click on [Start firmware update].

- View "FW-Update" appears.
- State LED lights red.
- Dialog opens.




Figure 7.18: Advancing firmware update

The firmware is updated when:

- the view "FW-Update" disappears,
- the State LED goes out and
- the **[Close]** button is active.

[Index](#)

8 Maintenance provisions and safety regulations

Note according to standard EN55011:2009

The device is used in an industrial environment. Due to the occurring, conducted as well as radiated disturbances it possibly can be difficult to ensure electromagnetic compatibility in other environments.

Cleaning

The device may only be cleaned with a clean cloth slightly dampened with water. Other cleaning agents such as gasoline, alcohol, etc., may not be used.

Maintenance

The device is maintenance-free. The case must not be opened by the customer. Unauthorized modifications will void the warranty.

In case of failure, the customer may change the fuse on the cable set or fuses accessible from outside only. The fuse may only be replaced with a fuse of the same type and nominal current rating.

Storage

The device may only be stored within a temperature range of - 40 °F to + 185 °F.

Disposal

Disposal of the device must be in accordance with the statutory regulations.

8.1 Operating conditions

8.1.1 Temperature

The device must not be operated outside the specified temperature range. Adequate ventilation must be ensured. The device must not be placed too close to walls or other devices. The device must not be stacked with other components on each other unless proper ventilation is ensured and the device is to be operated at an ambient temperature of more than 77 °F.

8.1.2 Condensation

The device must not be switched on immediately when brought from cold ambient conditions into a room with normal ambient conditions.

8.1.3 Environment

The device must not be used outdoors or in adverse ambient conditions such as moisture, high humidity or dust. Operation of the device is further not allowed in an environment with flammable or explosive gases.

[Index](#)

8.1.4 Mechanical action

Altitude: - 300 to + 5500 m

Shaking at 2 ms sine half-wave	300 G
Vibration sine wave	3 G (10 – 50 Hz)
	2.5 G (50 – 2000 Hz)
	2 G (200 – 5000 Hz)

Out of operation environment

Altitude: - 300 to + 12000 m

Shaking at 1 ms sine half-wave	800 G
Vibration sine wave	up to 5 G (10 – 500 Hz)

8.2 Assembly

8.2.1 Cable sets

When inserting the cable sets only little force may be applied. The pins should be checked for correct alignment if increased resistance is felt during insertion of the cable set.

Only original Telemotive components may be used. Other components such as special cable sets must be prepared in strict accordance with the connector pin assignment in the operating instructions, always providing for a spare fuse in the cable set.

Clamp 15 (KL 15) serves as an external wake-up input. It can be used to wake up the device in case of edge change. KL 15 requires a voltage range of 0 to 30 V.

Two pins each designated Clamp 30 (KL 30) and Clamp 31 (KL 31) are interconnected for the power supply of the device.

Important:

A short circuit between KL 30 and KL 31 directly at the plug results in destruction of the device.

The maximum value of the power supply must not exceed 30 V. In case of overvoltage the device can be destroyed and the warranty will be voided.

8.2.2 Mounting

The device must only be mounted in the six axes.

In laboratory set-ups and especially in the vehicle the device must be mounted so that it is secured against falling, slipping and skidding.

8.2.3 Positioning of antenna

When the device is operated in a car, the antennas to be connected to the device must not be located outside the vehicle.

8.3 Proper operation

- The Remote Control Touch must exclusively be operated with the Telemotive AG application.
- The application is only compatible with Telemotive System Client.
- Connection with third-party devices is at your own risk.
- Its use while driving is at your own risk.
If you are using the device while driving, we strongly recommend to focus your attention on the road traffic and the safety regulations according to local road traffic regulations. (see Figure 6.16: Popup in Launcher view)

Any use other than described results in damage to the product. It also involves risks such as short circuit, fire, electric shock, etc. The entire product may not be modified or adapted.

9 Data sheet

General data	
Supply voltage	13.8 V
Power unit voltage	5 to 30 V (the logger requires > 7 V at system startup)
Supply voltage reverse-connect protection	yes
Short circuit proof	yes
Operating current (typ.)	350 mA (@ 13.8 V)
Operating current (max.)	< 1000 mA (@ 13.8 V)
Power consumption in standby	< 1 mA
EMC	according to CE
ESD	4 kV contact discharge 8 kV air discharge
CE label	TBD
Operating temperature	- 4 °F to + 158 °F
Storage temperature	- 40 °F to + 185 °F
Weight (approx.)	410 g
Power management	
Startup time from standby to full operation	35 s
Wake-up capability	LS-CAN, KL 15, trigger button
Case	
Dimensions (approx.)	5.91" x 3.62" x 0.98" (150 x 92 x 25 mm)
Operating elements	Home button
State/Active LEDs	yes
Connections	
Side view, from the right	8-pol LEMO socket: Power supply, 1x LS-CAN 2x Gbit Ethernet (RJ45)
Rear side	4-pol audio jack plug stereo out/microphone (3.5 mm) OMTP Mini USB 2.0
Screen	
Size	5"
Resolution	800 x 480
Colors	16.7 million
Luminance	700 cd/m ²
Touch function	Resistive, multi-touch

Table 9.1: Data sheet
[Index](#)

10 Abbreviations

Abbreviation	Meaning
blue PiraT	Processing Information Recording Analyzing Tool
bP	blue PiraT
bP2	blue PiraT2
bP2 HW2.x	blue PiraT2 Hardware 2.x
bPMini	blue PiraT Mini
TSL	Telemotive System Link
TSC	Telemotive System Client
CAN	Controller Area Network
LIN	Local Interconnect Network
MOST	Media Oriented Systems Transport (www.mostnet.de)
ECL	Electrical Control Line
MEP	MOST Ethernet Packet
USB	Universal Serial Bus
CF	Compact Flash
SD	Secure Digital
LAN	Local Area Network = Netzwerk
FW	Firmware
PW	Password
SFTP	Secure File Transfer Protocol
SHA	Secure Hash
SSL	Secure Sockets Layer
TLS	Transport Layer Security
TMP	Telemotive Packetformat
UTC	Universal Time, Coordinated
GMT	Greenwich Mean Time

Table 10.1: Abbreviations

[Index](#)

11 List of figures

Figure 5.1: Top view with components	8
Figure 5.2: Side view, from the right with components.....	9
Figure 5.3: Rear side view with components	9
Figure 5.4: Power cable with LEMO connector to banana plug.....	12
Figure 5.5: TSL network with one bPMini, one Remote Control Touch and one bP2 (e.g.).....	13
Figure 5.6: TSL Client Portal	14
Figure 5.7: Shortcut to Telemotive System Client	15
Figure 5.8: Opening the Telemotive System Client manual	15
Figure 5.9: Viewing the devices in the client	16
Figure 5.10: Activating TSL	16
Figure 5.11: Representation of the TSL compound in the client.....	16
Figure 6.1: Application sitemap	18
Figure 6.2: Components of the application views.....	19
Figure 6.3: Home view.....	20
Figure 6.4: Tab sheet “Overview”	21
Figure 6.5: Tab sheet “*Device name n*”	22
Figure 6.6: Tab sheet “Functionkeys”	22
Figure 6.7: Tab sheet “Markerlist”	23
Figure 6.8: Tab sheet “CAN”	23
Figure 6.9: Tab sheet “MOST150”	24
Figure 6.10: Tab sheet “MOST150”: Light off	24
Figure 6.11: Tab sheet “GPS”	25
Figure 6.12: Tab sheet “GPS” – continuation.....	25
Figure 6.13: Tab sheet “GPS”: No GPS signal	25
Figure 6.14: FW-Update view	29
Figure 6.15: Launcher view	30
Figure 6.16: Popup in Launcher view	30
Figure 6.17: Window “RC Monitor”	31
Figure 6.18: Window “RC Text”	32
Figure 6.19: Standby view	32
Figure 6.20: Tab “Network Logger” in the TSL network	33
Figure 6.21: Tab “Network Logger” in standalone mode.....	34
Figure 6.22: Configuration trees: Standalone mode (left) – TSL (right).....	35
Figure 7.1: Fade-in after adjusting the brightness.....	37
Figure 7.2: Fade-in after adjusting the volume.....	37
Figure 7.3: Example side menu	38
Figure 7.4: Voice note duration display.....	38
Figure 7.5: Expanding trigger folder.....	40
Figure 7.6: Notice message for missing settings.....	41
Figure 7.7: Error message due to unauthorized configuration.....	41
Figure 7.8: Functionkeys with complex triggers	42
Figure 7.9: Context menu of a trigger	42
Figure 7.10: Voice note recording starts	43
Figure 7.11: Voice note recording stops	44
Figure 7.12: Marker set	44
Figure 7.13: Tab “Firmware- / Licenses update”	46
Figure 7.14: Opening firmware-packet.....	46
Figure 7.15: Valid firmware-packet	47
Figure 7.16: Notice message for invalid firmware-packet.....	47
Figure 7.17: Notice message before firmware update	47
Figure 7.18: Advancing firmware update	48

12 List of tables

Table 5.1: Available connections	10
Table 5.2: LED behavior	11
Table 6.1: Application overview	20
Table 6.2: Operating elements of the tab sheet "General"	26
Table 6.3: Displays overview	27
Table 6.4: Device status messages	28
Table 6.5: Device types	28
Table 6.6: Message categories	28
Table 9.1: Data sheet	52
Table 10.1: Abbreviations	53

[Index](#)

13 Contact



Telemotive AG

Office München
Frankfurter Ring 115a
80807 München

Tel.: +49 89 357186-0
Fax.: +49 89 357186-520
E-Mail: info@telemotive.de
Web: www.telemotive.de

Sales
Tel.: +49 89 357186-550
Fax.: +49 89 357186-520
E-Mail: sales@telemotive.de

Support
Tel.: +49 89 357186-518
E-Mail: productsupport@telemotive.de
ServiceCenter: <https://sc.telemotive.de/bluepirat>