



# blue PiraT2 / 5E / Mini / Remote Measurements with CCP/XCP User Guide

Version 2.4.1 / 22.09.2016



## Table of contents

<b>1</b>	<b>LICENSE AGREEMENT .....</b>	<b>3</b>
<b>2</b>	<b>PRODUCT LIABILITY .....</b>	<b>4</b>
<b>3</b>	<b>Overview .....</b>	<b>5</b>
<b>4</b>	<b>System requirements .....</b>	<b>6</b>
4.1	Further manuals .....	7
<b>5</b>	<b>System overview / description .....</b>	<b>8</b>
5.1	Setup and configuration.....	8
5.2	Operating and data recording .....	8
5.3	Download and conversion .....	9
<b>6</b>	<b>Setup and configuration .....</b>	<b>10</b>
6.1	Creating a new ECU.....	10
6.2	Tab [Configuration].....	15
6.2.1	Status.....	15
6.2.2	Delete this ECU.....	16
6.2.3	ECU Name .....	16
6.2.4	EPK.....	16
6.2.5	ECU Address (Hex).....	17
6.2.6	Byte Order.....	17
6.2.7	Timeout (ms).....	17
6.2.8	Busload max. ....	18
6.2.9	Protocol Version.....	18
6.2.10	ECU connection.....	18
6.3	Tab [Protocol].....	20
6.3.1	Protocol CCP/XCP on CAN .....	20
6.3.2	Protocol XCP on TCP/UDP .....	22
6.4	Tab [Measurement] .....	24
6.4.1	Start and Stopevent.....	24
6.4.2	Signals and DAQs .....	25
6.5	Tab [Seed & Key] .....	31
6.5.1	Functionality .....	31
6.5.2	Settings .....	31
6.6	General settings .....	33
<b>7</b>	<b>Data recording .....</b>	<b>35</b>
7.1	Display of the RCTouch / blue PiraT Remote .....	35
7.2	Display of the Remote Control (Voice).....	36
7.3	Display of the blue PiraT2 / 5E .....	37
7.4	Online Monitor .....	38
7.4.1	Starting Online Monitor.....	38
<b>8</b>	<b>Download and conversion .....</b>	<b>40</b>
8.1	Conversion .....	41
<b>9</b>	<b>Abbreviations .....</b>	<b>42</b>
<b>10</b>	<b>List of figures.....</b>	<b>44</b>
<b>11</b>	<b>List of tables .....</b>	<b>46</b>
<b>12</b>	<b>Contact.....</b>	<b>47</b>

# 1 LICENSE AGREEMENT

Please read the license agreement of this license contract carefully, before you install the software. By the installation of the software you agree to the conditions of this license contract. This software-license agreement, in the following called "license", contains all rights and restrictions for final users that regulate the use of the accompanying software, operating instructions and other documents, in the following called as "software".

1. This license contract is an agreement between licensor and licensee, who is being licensed to use the named software.
2. Licensee acknowledges that this is only a limited nonexclusive license. This means, that the licensee has no right to allocate sublicenses. Licensor is and remains the owner of all titles, rights and interests in the software.
3. The software is a copyright property of the Telemotive AG. The program or parts of it may not be further licensed to third parts, rented, sold or be further marketed in any form without explicit written approval by Telemotive AG. The user may neither change the software and their components, nor modify, nor redevelop or decompile otherwise in any form.
4. This software is subject to no warranty. This software is sold as is, without any warranty. If at any time, a user changes his system, we hold no responsibility to change our software to make it work again.
5. This license permits licensee to install the software on more than one computer system, as long as the software will not be used on more than one computer system simultaneously. Licensee will not make copies of the software or allow copies of the software to be made by others, unless authorized by this license agreement. Licensee may make copies of the software for backup purposes only. Licensee is not entitled to transmit or to transfer the software or its rights from this license agreement.
6. Licensor is not liable to licensee for any damages, including compensatory, special, incidental, exemplary, punitive or consequential damages, connected with or resulting from this license agreement or licensee's use of this software.
7. Licensee agrees to defend and indemnify licensor and hold licensor harmless from all claims, losses, damages, complaints or expenses connected with or resulting from licensee's business operations.
8. Licensor has the right to terminate this license agreement and licensee's right to use this software upon any material breach by licensee. The duration of the license contract is indefinitely determined.
9. Licensee agrees to return all copies of the software to licensor or to destroy them upon termination of the license contract.
10. This license agreement replaces and supersedes all prior negotiations, dealings and agreements between licensor and licensee regarding this software.
11. This license contract is subject to German law.
12. If a regulation of this license contract is void by law, the validity of the remaining regulations is not affected. If there is such a regulation it will be replaced by a valid, according to the legal regulations and enforceable regulation with similar intention and similar economic consequence.
13. The license contract is effective by delivery of the software of the licensor to the licensee and/or by usage of the software by the licensee. This license contract is also valid without licensor's signature.
14. The license automatically goes out if the licensee does not agree to the license regulations described here or offend against the license regulations of this license contract. With ending the license contract the licensee is obliged to extinguish or to destroy the software and all copies of it no matter if installed or stored on disk or to hand all of it back to Telemotive AG.
15. The licensee is liable for all damages caused to the licensor by the violation of these license regulations.

## 2 PRODUCT LIABILITY

For all offers, sales and supplies the following conditions apply exclusively, even if the buyer, orderer and suchlike prescribes other conditions. Alterations are only valid, if they are agreed in writing.

1. The technical documentation is part of the products. The product liability and the product guarantee will be excluded, if contents and in particular the safety references and instructions of the documentation are not considered.
2. The products do belong to the group of test tools. By application of the equipment a disturbance of the tested system cannot be completely excluded. For this reason, the warranty of a perfectly functioning system cannot be taken over by the manufacturer. Application of the product takes place at one's own risk.
3. The liability of the substitution of damages according to §1 product liability law is expressly excluded in the context of §9 product liability law, as far as compelling legal terms do not provide anything else.
4. In no event will the producer be liable for any indirect, incidental, special or consequential damages, including loss of profits, loss of revenues, loss of data, loss of use, any other economic advantage or damage caused by pretensions of third party towards the customer out of this agreement, under any theory of liability, whether in an action in contract, strict liability, tort (including negligence) or other legal or equitable theory.
5. The burden of proof is with the customer.
6. The Telemotive AG does ensure the legal warranty according to German law. Except for warranties expressly set forth in this agreement, any and all products are delivered "as is" and the producer makes and the customer receives no additional express or implied warranties. The producer hereby expressly disclaims any and all other warranties of any kind or nature concerning the products, whether express or implied, including without limitation, any warranty of title, merchantability, quality, accuracy or fitness for a particular purpose or the customer's purpose. The producer expressly disclaims any warranties that may be implied from usage of trade, course of dealing or course of performance. Except for the express warranties stated in this agreement the products are provided with all faults and the entire risk of unsatisfactory quality, performance, accuracy. The possible effort is with the customer. The producer does not warrant that the products will operate without interruption or be error free.
7. The Telemotive AG is justified to exchange defective goods against homogeneous acceptable ones or to eliminate the fault within an appropriate period. In this case a demand for redhibitory action or reduction of price expires. Warranty claims presuppose a due notice of defects.
8. Resale, transfer, donation, exchanges or the rental of the offered products at third party is permitted without clearance of the Telemotive AG.
9. German Law is deemed to be as legal basis.

### 3 Overview

This user guide describes the feature of the license **CAN Calibration Protocol (CCP)** and **Extended Calibration Protocol** {Universal Measurement and Calibration Protocol} (**XCP**) for the data loggers:

- blue PiraT2
- blue PiraT2 5E
- blue PiraT Mini
- blue PiraT Remote

of Telemotive AG.

This user guide describes the configuration and usage of this feature. The general configuration is described in the user guides of the used data logger as well as the Telemotive System Client, which is valid together.

The client software was only tested with Microsoft® Windows® 7.

This document refers to **firmware version 02.04.01** and the **Telemotive System Client** from **version 2.4.1**. Some features depending on model and feature license or may not be available in older versions.

Software updates and user guides for other, optional, licensed enhancements are available in the Telemotive ServiceCenter. *(Please find the address under Contact at the last page.)*

To ensure the most reliable operation of your system as possible, please make sure to use always current firmware and software versions.

[Index](#)

## 4 System requirements

### Control Unit

A Windows based Laptop or PC is needed to configure the devices of Telemotive AG by **Telemotive System Client**. It also allows to save the recorded data and to use them offline later.

### Telemotive System Client

The software client is used for configuring the data logger as well as downloading the recorded data or convert these into your needed file format. An firmware update can be performed by the **Telemotive System Client** too to ensure that your devices are always up to date.

### blue PiraT2 / blue PiraT2 5E / blue PiraT Mini

The communication between bus systems and control units is monitored and relevant data can be recorded very precisely with the data logger of Telemotive AG. The collected data are stored to the logger and can be downloaded via Ethernet to a PC.

The **blue PiraT2** is our top-class all-in-one data logger. Seven models cover a wide range of interfaces.

Additionally, the **blue PiraT2 5E** offers improved power management and power backup, five integrated Ethernet ports and super-fast start-up behavior. The blue PiraT2 can be flexibly expanded via [Telemotive System Link](#).

The **blue PiraT Mini** is smallest data logger in the world with an outstanding functional scope. It offers a wide range of interfaces, stable temperature behavior, very low energy consumption, four GBit Ethernet ports, and much more. Different blue PiraT Mini can be flexibly expanded to one cluster and therefore handled very easily by using [Telemotive System Link](#).

### Remote Control Touch

Operate your blue PiraT Mini or blue PiraT2 data loggers safely and comfortably from the driver's or passenger seat. Via Telemotive System Link our new remote control becomes part of your logger network. One remote control can handle all connected loggers.

### blue PiraT Remote

While Remote Control Touch is just a control unit for handling unique devices or a TSL network, the blue PiraT Remote additional has logger functionality by offering internal storage and some interfaces.

### A2L file

This file defines parameters which are necessary to set up a CCP/XCP communication between the Telemotive data logger and an ECU. Each ECU has its own A2L file, so it cannot be provided by Telemotive AG. Please contact the respective ECU manufacturer to get a valid file.

### License

For the additional feature **Logging CCP / XCP** an installed license is required. Settings for licensed features can be performed with a valid license only.

If you need a license for your logger, please contact our sales department (please find the address under contact at the last page).

## 4.1 Further manuals

Beside this user guide we offer the main manuals for our client as well as for the different data logger generations in our ServiceCenter at <https://sc.telemotive.de/bluepirat>.

### User manual for the Telemotive System Client

[https://sc.telemotive.de/4/uploads/media/TelemotiveSystemClient\\_UserManual.pdf](https://sc.telemotive.de/4/uploads/media/TelemotiveSystemClient_UserManual.pdf)

### User manual for blue PiraT2 / blue PiraT2 5E

[https://www.telemotive.de/4/uploads/media/blue\\_PiraT2\\_UserManual.pdf](https://www.telemotive.de/4/uploads/media/blue_PiraT2_UserManual.pdf)

### User manual for blue PiraT Mini

[https://www.telemotive.de/4/uploads/media/blue\\_PiraT\\_Mini\\_UserManual.pdf](https://www.telemotive.de/4/uploads/media/blue_PiraT_Mini_UserManual.pdf)

### User manual for Remote Control Touch

[https://sc.telemotive.de/4/uploads/media/RCTouch\\_UserGuide.pdf](https://sc.telemotive.de/4/uploads/media/RCTouch_UserGuide.pdf)

### User manual for blue PiraT Remote

[https://sc.telemotive.de/4/uploads/media/blue\\_PiraT\\_Remote\\_UserGuide.pdf](https://sc.telemotive.de/4/uploads/media/blue_PiraT_Remote_UserGuide.pdf)

For having an easy access if necessary, the most important manuals are linked in the client under the menu item **[Help]** and are reachable easily from there.




Figure 4.1: links to the manuals

Our licensed enhancements have own manuals which are stored in the ServiceCenter too. You will find a list of these enhancements in the user manuals in the chapter **Additional features by optional licenses**.

[Index](#)

## 5 System overview / description

For an easy system overview, we can separate the system into three basic parts:

1. Setup and configuration
2. Operating and data recording
3. Download and conversion

In general, the system is used to get a Telemotive Trace File or MDF file v3.3 / v4.1 that includes the CCP/XCP communication.

### 5.1 Setup and configuration

The A2L file (delivered by the ECU supplier) is loaded into the Telemotive System Client. If necessary, connection and communication settings can be modified. When the configuration is finished, the Telemotive System Client can upload the configuration to the data logger.




Figure 5.1: Setup and configuration

### 5.2 Operating and data recording

The data logger and the ECU work as configured. The CCP/XCP protocol is running. The data logger records the data.




Figure 5.2: Operating and data recording



### 5.3 Download and conversion

After recording, the data can be downloaded from the data logger or converted directly into the target data format by the Telemotive System Client.




Figure 5.3: Download and conversion


[Index](#)

## 6 Setup and configuration

### 6.1 Creating a new ECU

At first connect the data logger to your computer and start the Telemotive System Client.

Click on the application **[Open configuration]** in the Telemotive System Client.




**Figure 6.1: Folder in configuration tree**

Expand the folder **[CCP/XCP]** in the configuration tree.

**Note:**


If you only installed the CCP license, the folder is just named “CCP”.



**Figure 6.2: Add ECU**

By double-clicking the button **[Add ECU...]** the **A2L Loading wizard** appears, where you can select the A2L file with the configuration data of the ECU and an INCA file with signal /DAQ selection.

[Index](#)



**Figure 6.3: A2L Loading wizard**


**Attention:**

The A2L file has to match the ECU and its hard- and software version. Otherwise the read or write addresses can be wrong and the CCP/XCP communication does not work correctly. Please contact the respective ECU manufacturer to get a valid file.

By clicking on the button **[Next>]** the A2L file and / or the INCA file will be imported and loaded on the logger.

If the file is not correct or has wrong settings, an error message is shown and the import is stopped..


Next, you get to the **Select Transport Protocol Wizard**.



**Figure 6.4: Select Transport Protocol wizard**

With this wizard, you are able to select the ECU-specific connection.

If no INCA file was specified earlier in the **A2L Loading wizard**, the **Signal selection wizard** appears.




**Figure 6.5: Signal selection wizard**

With this wizard, it is possible to select one or more signals for the measurement. The measurement can contain up to 1,000 signals.


With the button **[Search]**, the signals can be specifically selected from the A2I database:

[Index](#)



**Figure 6.6: Select signals via the search function**


If an INCA-file was specified earlier in the **A2L Loading wizard**, the **Choose device wizard** appears.



**Figure 6.7: Choose device wizard**

With the **Choose device wizard** you can select your device over the selection window **Devicename**.

According to the selection of the device, specific signals are added for measurement.




**Figure 6.8: selected signals by INCA-file**

By clicking on a signal its details are displayed in the middle window.

You can change the preselection using the button [Remove]. You can remove whole signal groups as well as single signals within the group.

After clicking [**Finish**], a new ECU is displayed in the configuration tree (e.g. ECU # 1). Up to four controllers can be created.



**Figure 6.9: Newly added ECU**

**Note:**

The parameters are predefined by the A2L file. Please change these parameters only if you exactly know their importance and the effects that follow it.

## 6.2 Tab [Configuration]




Figure 6.10: Example ECU configuration

### 6.2.1 Status

Delete and disable over the context menu (right mouse button) in the configuration tree:





Figure 6.11: Deleting and deactivating the ECU

Each ECU can be enabled or disabled by the right mouse button in the configuration tree and via the checkbox **Activate ECU**.

[Index](#)




**Figure 6.12: Checkbox "Activate ECU"**

If an ECU is inactive, its parameters are still kept in the configuration, but there is no CCP/XCP communication between data logger and ECU.

### 6.2.2 Delete this ECU

The button **[Delete this ECU]** deletes the marked ECU. It is also possible to delete via the right mouse button in the configuration tree.



**Figure 6.13: Delete this ECU**


### 6.2.3 ECU Name



**Figure 6.14: Textbox "ECU Name"**

In the text field **[ECU Name]** you can change the ECUs name. This option is only for an easy identification by the user and has no influence on the measurement or connection.

### 6.2.4 EPK



**Figure 6.15: Box "EPK"**

The version identifier of the A2L-file is presented here if available.

[Index](#)



## 6.2.5 ECU Address (Hex)

ECU Address (Hex):	01
--------------------	----

**Figure 6.16: Box "ECU Address (Hex)"**

**Note:**

The field [ECU Address (Hex)] is only needed for CCP ECUs. It is not displayed for XCP measurements.

In the text field <ECU Name> the ECU station address is indicated which is needed for establishing the communication to the ECU. It always has to be defined in Intel Byte Order although the following communication is in Motorola Byte Order.

When this address is wrong, the ECU does not establish the communication to the logger. The ECU station address is defined by the manufacturer of the ECU and is received only from him, if it's not noticed in the A2L file.

## 6.2.6 Byte Order

Byte Order:	INTEL
Timeout (ms):	INTEL MOTOROLA

**Figure 6.17: Box "Byte Order"**

In the dropdown menu next to [Byte Order] you can choose one of the following settings for the communication:

- Motorola (Big Endian)
- Intel (Little Endian)

## 6.2.7 Timeout (ms)

Timeout (ms):	2000
Timeout (ms) for DAQ-messages	2000

**Figure 6.18: Box "Timeout (ms)"**

In the text fields [Timeout (ms)] and [Timeout (ms) for DAQ-messages] you can define the time in milliseconds the logger waits for an answer from the ECU. When this time ends without an answer from the ECU the communication between the ECU and the logger will be stopped.

**Note:**

If the connection fails increase the value of the timeout.

## 6.2.8 Busload max.

**Figure 6.19: Box "Busload max."**

With the setting [**Busload max.**] you can limit the whole CCP/XCP communication on the selected CAN channel to a defined value. If the CCP/XCP busload reaches this value, additional messages get lost.

## 6.2.9 Protocol Version

**Figure 6.20: Protocol Version**

The protocol version is taken from the A2L file.  
The supported protocol versions are XCP 1.0, 1.1 and 1.2 and the CCP version 2.1.

## 6.2.10 ECU connection

If the connection gets lost or the ECU has not yet started up to link time, a continuous query **all 10 seconds** can be realized with the lower checkbox **Automatic reconnect / ECU polling on startup**.

**Figure 6.21: Connection Attempts**

**Note:**


**In the standard configuration [Automatic reconnect / ECU polling on startup] is selected and the connection attempts are set to 30.**


With this configuration the logger transmits one CAN message every ten seconds on the chosen CAN channel.

For the case that the options [Wakeup system] or [Keep awake on busload] are active, the data logger won't switch to standby mode, as long as connection requests persist. To avoid this the number of connection requests may be configured on an individual basis.


[Index](#)

Therefore various warnings in the client are displayed in the standard configuration:






Also if you want to send this configuration to the logger, a warning message appears:



**Figure 6.22: Warning notice in case of the chosen option “automatic reconnection”**

## 6.3 Tab [Protocol]

On the **[Protocol]** tab sheet you can define some settings depending on your used bus and ECU protocol (CCP/XCP).




**Figure 6.23: Protocol tab**

The logger supports the transport layers CAN and Ethernet (TCP and UDP) for XCP. Please find the protocol and, if available, the bus system in brackets:

- CCP (Note: vehicle bus is always CAN)
- XCP over CAN
- XCP over TCP (Ethernet)
- XCP over UDP (Ethernet)


### 6.3.1 Protocol CCP/XCP on CAN



**Figure 6.24: CAN Channel selection field**


Please select the required CAN channel.

By clicking on the link **[Go to channel Settings]** you'll be forwarded to CAN channel setup.




**Figure 6.25: CAN interface active and Acknowledge On**

The selected CAN channel has to be activated in the CAN settings as well as the checkbox **Acknowledge ON**.



**Figure 6.26: Set Baudrate**

The [Baudrate] of the ECU is read out from the A2L file. If the value does not match to the configured baud rate of the channel (in this case “CAN-HS #1”) the Telemotive System Client shows an error message in red at the bottom of the window.



**Figure 6.27: Error message due to different baud rates**

To correct these settings you can directly use the link nearby to go to the according CAN channel settings (in this case “CAN-HS #1”) and there set the [Baudrate] to the value of the respective CCP/XCP ECU which is defined in the A2L file (see Figure 6.26: Set Baudrate).

The screenshot shows two configuration sections. The top section is titled 'Master (Logger)' and contains a text input for 'CAN ID (Hex):' with the value '07fd'. Below it, 'Frame Type:' has two radio buttons: 'Base' (selected) and 'Extended'. The bottom section is titled 'Slave (ECU)' and contains a text input for 'CAN ID (Hex):' with the value '07fe'. Below it, 'Frame Type:' has two radio buttons: 'Base' (selected) and 'Extended'.

**Figure 6.28: Setting group "Master and Slave"**

In the settings for **[Master (Logger)]** and **[Slave (ECU)]** you can set the **[CAN ID (Hex)]** and the **[Frame Type]** of the communication.

For 11 bit CAN ID activate **Base**.

For 29 bit CAN ID activate **Extended**.

All CAN messages between ECU and logger have these CAN IDs. All other CAN messages on the bus will be ignored. When the CAN-IDs are wrong, the ECU doesn't answer.

The screenshot shows a 'Message Size:' label followed by two radio buttons. The first radio button is labeled 'Maximal size' and is selected. The second radio button is labeled 'Optimal size' and is not selected.

**Figure 6.29: Message Size**

When using XCP on CAN the **[Message Size]** is another option in the **[Protocol]** tab sheet.

If the messages shall contain only the user data, activate **[Optimal size]**.

If fill-bytes shall be added too, activate **[Maximal size]**.

### 6.3.2 Protocol XCP on TCP/UDP

The screenshot shows a window titled 'Select Transport Protocol wizard (Configure measurement)'. Inside, there is a label 'Transport Protocol:' followed by a dropdown menu. The dropdown menu is open, showing a list of options: '0: CAN' (highlighted in blue), '1: CAN', '2: TCP', and '3: UDP'.


**Figure 6.30: Transport Protocol selection**

Whether TCP or UDP is used is predefined either by the A2L-File or can be chosen with **[Select Transport Protocol wizard (Configure measurement)]**.

See also chapter 6.1 Creating a new ECU

The configuration of XCP on TCP and XCP on UDP are not different. Communication with the ECU via TCP/UDP does not take place via an Ethernet channel. A new set of communication endpoint is responsible only for the ECU communication.

For this a new IP-alias of the logger is determined in the protocol. The IP address and port of the ECU have to be entered in the fields **[Target IP address]** and **[Port]**. The **[IP Address of data logger]** has to be at the same subnet as that of the ECU. With the dropdown menu of the **[Connector]** you can select the interface of the logger (“Front” or “Back”).




Configuration	Protocol (XCP on UDP)	Measurement
Ethernet		
Connector:	Back	
Target IP address:	169 . 254 . 10 . 1	
Port:	1802	
IP Address of data logger:	169 . 254 . 0 . 1	
Subnet Mask:	255 . 255 . 0 . 0	
Transport Version:	v1.0	

Figure 6.31: XCP on UDP

## 6.4 Tab [Measurement]

### 6.4.1 Start and Stopevent

For each ECU a start and stop event can be defined on the tab sheet **[Measurement]**. As events startup/shutdown of the logger and trigger can be selected.




**Figure 6.32: Select event**

**Attention:**

To define a trigger as start or stop event, maybe the license “Complex triggers” is necessary. You have two triggers for free by default. If you need more, you have to install the license.

To use a trigger for CCP/XCP, the trigger has to be defined in the settings for trigger at first.

In the settings of this trigger **[Execute CCP/XCP action]** must be selected.



**Figure 6.33: Trigger selection: "Excecute CCP/XCP action"**

For more information refer to the “TelemotiveSystemClient\_UserManual”.



## 6.4.2 Signals and DAQs

In the tab sheet **[Measurement]** the view can be changed between **[Signals]** and **[DAQs]** (DAQ lists). The DAQ lists are already predefined by the A2L file. Some of these lists allow editing the parameters.

Some A2L files contain static DAQ lists which can be filled with signals. Otherwise dynamic DAQ lists are generated from the added signals (with the same **[Start Condition]** and **[Measurement Mode]**).

Measurements	Start Condition	Measurement Mode	Interval
☒ DAQ #0 (10ms)	DEVICE_CONNECTED	10ms	10 ms
☒ DAQ #2 (Segment)	OFF	Segment	Cylinder segment
☒ DAQ #1 (Display)	OFF	Display	100 ms

separate start events  
for individual meas-  
urement

mode for individual  
measurement

time- or event-  
triggered interval


**Figure 6.34: Static DAQ lists**

[Index](#)

### 6.4.2.1 Adding Signals

To add individual signals to the current measurement you can:


- click **[Add Signals...]** or
- Right-click in the DAQ list and click **[Add Signals...]** in its shortcut menu.



**Figure 6.35: Add Signals**

A new window will be opened for selecting the signal.

A double-click on the required signal will automatically add it to the measurement. It is also possible to select multiple signals by marking them and clicking **[Finish]**.




**Figure 6.36: Selecting Signals**

Signals can be moved per “drag and drop” between the DAQ lists or they can be placed outside the DAQ lists.


### 6.4.2.2 Defining start conditions

For each signal which is not in a DAQ list a separate start condition can be defined. Likewise a start condition can be defined for a whole "DAQ" list .




**Figure 6.37: Defining different start conditions**

If the start condition of a signal from a DAQ list is changed in the [Signals] view, the start condition of the other signals from that DAQ list will be changed accordingly.



**Figure 6.38: Information window after changing the start condition**


As this is not recognizable in the "Signals" overview, a correspondent notification message box will appear in case a change should occur.



**Figure 6.39: Message box after changing start condition**

### 6.4.2.3 Set measuring mode

For signals and DAQ lists a Measurement Mode can be defined.



**Figure 6.40: Select Measurement Mode**

The dropdown content is usually defined in the A2L file. If options cannot be selected or changed, this is also defined in the A2L file.

In general three different measurement modes are distinguished, whereas in the "single" and "polling" modes, the data logger individually requests measurement data from the ECU. This measurement mode is only adjustable, if the signal is outside the scope of the "DAQ list". In the so-called DAQ-mode however, the ECU transmits the data to the logger in a specified cycle,

that is predetermined in the A2L file. Both the measurement modes "single" and "polling" cannot be adjusted for signals being within the scope of the "DAQ" list.

DAQ-mode: this measurement mode is not adjustable, only signals specified in the DAQ list are referred to as that.

In principle, three different types of measurement can be distinguished:

Name	Bedeutung
SINGLE	The data will be requested once.
POLLING	The data will be requested in cycle. This happens after a defined time interval.
DAQ	The data is configured once from the data logger within the ECU. The ECU will send the required data after an ECU internal defined event. (e.g., "10_ms" see figure above)

**Table 6.1: Possible measuring modes**


**Note:**

**In some cases the ECU software does not support all the Measurement Modes defined in the A2L file. If more than one Measurement Mode is configured for the same ECU and the CCP/XCP communication does not run, please try to configure only one Measurement Mode first. So you can isolate the problem and may have at least one or two working Measurement Modes.**


A signal or more can be deleted by marking it/them and clicking the button **[Remove Signals]**.

**6.4.2.4 Detailview**

Over the context menu (right mouse button) you get to the detailed view of the signals and DAQ list.



**Figure 6.41: DAQ-Details**



**Figure 6.42: Detail view of a DAQ list**

In this view, you can see the individual ODTs and their contents from which the DAQ list is composed.

## 6.5 Tab [Seed & Key]

### Note:

In the moment, Seed & Key is supported only by blue PiraT2 and only at CCP.

### 6.5.1 Functionality

With the feature "seed & key" the data logger supports an authorization check, which ensures that only legitimate persons can access the ECU through the CCP protocol. The data logger requests a so-called "seed" from the ECU. In combination with the preliminarily installed "seed & key" dll file, a so-called key is being generated. This key is sent by the data logger to the ECU for examination. In the event of a successful verification, the data logger can communicate with the ECU through the CCP protocol.

### 6.5.2 Settings

If the ECU supports [Seed & Key] at CCP, please check the settings in the corresponding tab.

These settings are taken from the A2L-file.

ECU #1 (TeMo) Delete this ECU

Configuration ⚠ Protocol (CCP) Measurement Seed & Key

Seed & Key Configuration

Active

DLL File:

Function Name:


Function Type:

Upload Seed & Key DLL

DLL:  Open File...


**Figure 6.43: Seed & Key Configuration**

Now the ECU specific Seed & Key DLL has to be upload to the logger.



**Figure 6.44: Seed & Key DLL**

If all configurations have been done, you may save the configuration via **[Save as file...]** or/and send it to the data logger via **[Write to logger]**.



**Figure 6.45: button bar below the ECU-settings**

A saved configuration can always be opened by the Telemotive System Client via **[Load from file...]**.

After writing the configuration to the data logger, the CCP/XCP communication should be working.

[Index](#)



## 6.6 General settings


You can configure the settings for the optional DBC file generation under **[General settings]**.

The DBC-file generation is supported for CCP and XCP. The DBC file is needed for Live View, complex triggers and for signal based actions.

For more information and settings please refer to the **TelemotiveSystemClient\_UserManual**.

### Note:

There is the following restriction: Only DAQ measurements can be supported (as multiplexed CAN signals). Single/polling measurements cannot be mapped in the DBC. In the response messages of the ECU only data is delivered and therefore the data cannot be assigned clearly to a signal in the DBC, as the data in principle could belong to different signals.




**Figure 6.46: General settings**

With the upper checkbox the data logger will create “.dbc” files. These files include details about the CCP/XCP data fields which are measured by using the DAQ lists.


With the lower checkbox you define, that new “.dbc” files overwrite the ones already existing in the target directory. The file name is generated by the Telemotive System Client.

### Note:



**Figure 6.47 : Warning at the same signal-shortnames**

The "virtual" signal shortnames may only be 32 characters long and must distinguish. By right-clicking on the signal the shortname can be adjust accordingly.



**Figure 6.48: Edit Signal Short Name**

To start the DBC Generation please click on the Button **[Write to Logger]**.

[Index](#)

## 7 Data recording

If the configuration has been written to the data logger and the device is working without errors, the CCP/XCP data are recorded continuously or event controlled, depending on the configuration.

### 7.1 Display of the RCTouch / blue PiraT Remote



**Figure 7.1: Remote Control Touch / blue PiraT Remote**

If an RCTouch / bP Remote is connected to the logger, you can display all available busses and their channels over the button **[Busload]** in the <Home>-View.

TSL: TSL_2_3 (2) Busload 22.02.2016 - 17:36:44		
Id	Name	Busload
#1	DUT_178_HSCAN-1	0 %
#2	DUT_178_HSCAN-2	0 %
#3	DUT_178_HSCAN-3	OFF
#4	DUT_178_HSCAN-4	OFF

CAN Serial LIN Ethernet Camera **CCP\_XCP**

**Figure 7.2: Busload view**

Press the button **[CCP XCP]** to display the CCP / XCP communication.

[Index](#)

<span>☰</span> <span>📶</span> TSL: Angelsachsen (2)      Busload      23.02.2016 - 11:27:44		
Id	Name	Busload
#1	ECU_1	4 Frames/sec

CAN	Serial	MOST25	FlexRay	LIN	Ethernet	Camera	<b>CCP_XCP</b>
-----	--------	--------	---------	-----	----------	--------	----------------

Figure 7.3: View "CCP\_XCP busload"

## 7.2 Display of the Remote Control (Voice)

If a Remote Control (Voice) is connected, a state message can be seen in the display. To get at this view press the Status button and use the Menu buttons to get to the page <CCP/XCP – CAN>. XCP on TCP/UDP is located under <XCP – ETH>. The display shows the states of up to four ECUs.





Figure 7.4: blue PiraT Remote Control Voice

```

▶ CCP/XCP - CAN13/15
[1] 20 [2] OFF
[3] OFF [4] OFF
Delta Busload/%
  
```

Figure 7.5: CCP/XCP on CAN

The number indicates the delta busload in percent (load in addition created by the CCP/XCP communication).



**Figure 7.6: XCP on TCP/UDP**

The number shows the incoming XCP frames per second.

Status	Meaning
OFF	ECU deactivated
N/C	ECU not connected
ERROR	Connection Error

ECU numbers that are configured with XCP on TCP/UDP will be marked as "OFF" on the <CCP/XCP – CAN> page and vice versa.

**Table 7.1: Other statuses at the display of the Remote Control (Voice)**

### 7.3 Display of the blue PiraT2 / 5E

The display of the **blue PiraT2 / 5E** also shows information about the CCP/XCP communication. The display can only show two lines. Please use the rotating knob until the CCP/XCP menu is shown. There are 4 characters showing the state of the ECUs. Each of the four letters displayed represents an ECU and displays its status.

Status	Meaning
–	not configured
X	not connected
T	Traffic
N	no traffic, connected
E	Connection Error

**Table 7.2: Status information at the display of the blue PiraT2 / 5E**




**Figure 7.7: Display of the blue PiraT2 / 5E**

## 7.4 Online Monitor

The online monitor enables the user to observe the measured data directly


### 7.4.1 Starting Online Monitor

To start the Online Monitor you have to activate the checkbox **Online Streaming active** in the sub-category **[Online Streaming]** and write it to the logger.





**Figure 7.8: Activating Online Streaming**

The tab <Online Monitor> can be opened by clicking the button **[Online Monitor] (2)**.




**Figure 7.9: Tab "Network Logger"**

There you can define which interfaces and channels you want to see in the Online Monitor and start the streaming by clicking the button  **[Start streaming]**. You can choose interface groups e.g all ECU's or individual ECU's.




**Figure 7.10: Starting online streaming**

Online streaming can be paused by the button **[Streaming pause]**



**Figure 7.11: Pausing online streaming**

There's no possibility to change the streamed channels when streaming is active. If you want to change some interfaces or channels you have to stop streaming before. To stop the streaming, please push the button **[Stop streaming]**. After changing the required settings you can start streaming again.



**Figure 7.12: Stopping online streaming**

For more information and settings of the online monitor, see the **TelemotiveSystemClient\_UserManual**.

[Index](#)

## 8 Download and conversion


The download application allows saving internal data (in Telemotive format) from the logger on the computers disk.

The conversion application allows saving internal data from the logger or an offline data set on the computers disk in a chosen format.

Connect the data logger to your computer and start the Telemotive System Client.

Select the corresponding data logger in the window <Network Logger> and click either the button:

- **[Download data] (3)**, to generate an offline data set from the logger's data, or
- **[Convert data] (4)**, to convert an offline data set or directly the logger's data to another format.



**Figure 8.1: Selecting logger**

Please find a detailed description for downloading and converting data in the manual of the Telemotive System Client:

### User manual for the Telemotive System Client

[https://sc.telemotive.de/4/uploads/media/TelemotiveSystemClient\\_UserManual.pdf](https://sc.telemotive.de/4/uploads/media/TelemotiveSystemClient_UserManual.pdf)

[Index](#)



## 8.1 Conversion


CCP/XCP data also can be converted directly without DBC file in MDF, Telemotive ASCII Format or Extended Telemotive Trace File.

Select in the channel list under **[CCP\_XCP]** the needed controller (using the unit number). Double clicking adds the channel directly to the output list (on the right side).

Select in the dropdown menu the output format:


- **[Telemotive ASCII Format (\*.txt)],**
- **[MDF CCP XCP Signal Format v3.3 (\*.mdf)],**
- **[MDF CCP XCP Signal Format v4.1 (\*.mf4)]** or
- **[Extended Telemotive Trace File (\*.xtmt)].**

Please repeat this for all required channels.



**Figure 8.2: Set output format**

The target directory combo box allows entering the name of the directory in which the converted data will be saved. Either you choose an entry from the dropdown menu or you open the dialog <Choose target directory> by clicking **[Change...]**.



**Figure 8.3: Selecting target directory**

By pressing the **[Convert]** button at the lower button bar the conversion can be started. All channels in the area for format settings will be written into the target directory in the selected format.



**Figure 8.4: Convert button**

**Note:**

From version 2.1.1 onwards ECU log messages (warnings, errors, notes) of MDF conversions are additionally written as TMASCII in a text file in the target directory.

## 9 Abbreviations

abbreviation	meaning
blue PiraT	<b>P</b> rocessing <b>I</b> nformation <b>R</b> ecording <b>A</b> nalyzing <b>T</b> ool
bP	<b>b</b> lue <b>P</b> ira <b>T</b>
bP2	<b>b</b> lue <b>P</b> ira <b>T2</b>
bP2 5E	<b>b</b> lue <b>P</b> ira <b>T2</b> 5E
bPMini	<b>b</b> lue <b>P</b> ira <b>T</b> Mini
A2L	<b>A</b> SAM <b>M</b> CD- <b>2</b> <b>M</b> C <b>L</b> anguage
AE	<b>A</b> utomotive <b>E</b> lectronics
ACK	<b>A</b> CKnowledged
CAN	<b>C</b> ontroller <b>A</b> rea <b>N</b> etwork
CCP	<b>C</b> AN <b>C</b> alibration <b>P</b> rotocol
CF	<b>C</b> ompact <b>F</b> lash
CRO	<b>C</b> ommand <b>R</b> eceive <b>O</b> bject
DAQ	<b>D</b> ata <b>A</b> cquisition
DTO	<b>D</b> ata <b>T</b> ransmission <b>O</b> bject
ECL	<b>E</b> lectrical <b>C</b> ontrol <b>L</b> ine
ECU	<b>E</b> lectronic <b>C</b> ontrol <b>U</b> nit
FIBEX	<b>F</b> ield <b>B</b> us <b>E</b> xchange <b>F</b> ormat
FW	<b>F</b> irmware
GMT	<b>G</b> reenwich <b>M</b> ean <b>T</b> ime
INCA	<b>I</b> Ntegrated <b>C</b> alibration and <b>A</b> pplication <b>T</b> ool
LAN	<b>L</b> ocal <b>A</b> rea <b>N</b> etwork = Netzwerk
LIN	<b>L</b> ocal <b>I</b> nterconnect <b>N</b> etwork
MAC	<b>M</b> edia <b>A</b> ccess <b>C</b> ontrol
MCD	<b>M</b> easure <b>C</b> alibrate <b>D</b> iagnose
MDX	<b>M</b> eta <b>D</b> ata <b>E</b> Xchange <b>F</b> ormat
MEP	<b>M</b> OST <b>E</b> thernet <b>P</b> acket
MOST	<b>M</b> edia <b>O</b> riented <b>S</b> ystems <b>T</b> ransport ( <a href="http://www.mostnet.de">www.mostnet.de</a> )
ODT	<b>O</b> bject <b>D</b> escriptor <b>T</b> able
ODX	<b>O</b> pen <b>D</b> ata <b>E</b> Xchange
OEM	<b>O</b> riginal <b>E</b> quipment <b>M</b> anufacturer

PHY	<b>PHY</b> sical Bus Connect
PW	<b>P</b> asswort
RX	<b>R</b> eceiver Data
SD	<b>S</b> ecure <b>D</b> igital
SFTP	<b>S</b> ecure <b>F</b> ile <b>T</b> ransfer <b>P</b> rotocol
SHA	<b>S</b> ecure <b>H</b> ash
SSL	<b>S</b> ecure <b>S</b> ockets <b>L</b> ayer
TCP/IP	<b>T</b> ransmission <b>C</b> ontrol <b>P</b> rotocol/ <b>I</b> nternet <b>P</b> rotocol
TLS	<b>T</b> ransport <b>L</b> ayer <b>S</b> ecurity
TMP	<b>T</b> elemotive <b>P</b> acketformat
TSC	<b>T</b> elemotive <b>S</b> ystem <b>C</b> lient
TSL	<b>T</b> elemotive <b>S</b> ystem <b>L</b> ink
UDP	<b>U</b> ser <b>D</b> atagram <b>P</b> rotocol
USB	<b>U</b> niversal <b>S</b> erial <b>B</b> us
UTC	<b>U</b> niversal <b>T</b> ime, <b>C</b> oordinated
Wi-Fi	<b>W</b> ireless <b>F</b> idelity
WLAN	<b>W</b> ireless <b>L</b> ocal <b>A</b> rea <b>N</b> etwork
XCP	Universal Measurement and <b>C</b> alibration <b>P</b> rotocol

**Table 9.1: Abbreviations**
[Index](#)

## 10 List of figures

Figure 4.1: links to the manuals .....	7
Figure 5.1: Setup and configuration .....	8
Figure 5.2: Operating and data recording .....	8
Figure 5.3: Download and conversion .....	9
Figure 6.1: Folder in configuration tree .....	10
Figure 6.2: Add ECU .....	10
Figure 6.3: A2L Loading wizard .....	11
Figure 6.4: Select Transport Protocol wizard .....	11
Figure 6.5: Signal selection wizard .....	12
Figure 6.6: Select signals via the search function .....	13
Figure 6.7: Choose device wizard .....	13
Figure 6.8: selected signals by INCA-file .....	14
Figure 6.9: Newly added ECU .....	14
Figure 6.10: Example ECU configuration .....	15
Figure 6.11: Deleting and deactivating the ECU .....	15
Figure 6.12: Checkbox "Activate ECU" .....	16
Figure 6.13: Delete this ECU .....	16
Figure 6.14: Textbox "ECU Name" .....	16
Figure 6.15: Box "EPK" .....	16
Figure 6.16: Box "ECU Address (Hex)" .....	17
Figure 6.17: Box "Byte Order" .....	17
Figure 6.18: Box "Timeout (ms)" .....	17
Figure 6.19: Box "Busload max." .....	18
Figure 6.20: Protocol Version .....	18
Figure 6.21: Connection Attempts .....	18
Figure 6.22: Warning notice in case of the chosen option "automatic reconnection" .....	19
Figure 6.23: Protocol tab .....	20
Figure 6.24: CAN Channel selection field .....	20
Figure 6.25: CAN interface active and Acknowledge On .....	20
Figure 6.26: Set Baudrate .....	21
Figure 6.27: Error message due to different baud rates .....	21
Figure 6.28: Setting group "Master and Slave" .....	22
Figure 6.29: Message Size .....	22
Figure 6.30: Transport Protocol selection .....	22
Figure 6.31: XCP on UDP .....	23
Figure 6.32: Select event .....	24
Figure 6.33: Trigger selection: "Execute CCP/XCP action" .....	24
Figure 6.34: Static DAQ lists .....	25
Figure 6.35: Add Signals .....	26
Figure 6.36: Selecting Signals .....	26
Figure 6.37: Defining different start conditions .....	27
Figure 6.38: Information window after changing the start condition .....	27
Figure 6.39: Message box after changing start condition .....	28
Figure 6.40: Select Measurement Mode .....	28
Figure 6.41: DAQ-Details .....	29
Figure 6.42: Detail view of a DAQ list .....	30
Figure 6.43: Seed & Key Configuration .....	31
Figure 6.44: Seed & Key DLL .....	32
Figure 6.45: button bar below the ECU-settings .....	32
Figure 6.46: General settings .....	33
Figure 6.47 : Warning at the same signal-shortnames .....	33
Figure 6.48: Edit Signal Short Name .....	34
Figure 7.1: Remote Control Touch / blue PiraT Remote .....	35
Figure 7.2: Busload view .....	35

Figure 7.3: View "CCP_XCP busload" .....	36
Figure 7.4: blue PiraT Remote Control Voice .....	36
Figure 7.5: CCP/XCP on CAN .....	36
Figure 7.6: XCP on TCP/UDP .....	37
Figure 7.7: Display of the blue PiraT2 / 5E .....	37
Figure 7.8: Activating Online Streaming .....	38
Figure 7.9: Tab "Network Logger" .....	38
Figure 7.10: Starting online streaming .....	39
Figure 7.11: Pausing online streaming .....	39
Figure 7.12: Stopping online streaming .....	39
Figure 8.1: Selecting logger .....	40
Figure 8.2: Set output format .....	41
Figure 8.3: Selecting target directory .....	41
Figure 8.4: Convert button .....	41

[Index](#)

## 11 List of tables

Table 6.1: Possible measuring modes.....	29
Table 7.1: Other statuses at the display of the Remote Control (Voice).....	37
Table 7.2: Status information at the display of the blue PiraT2 / 5E.....	37
Table 9.1: Abbreviations.....	43

[Index](#)

## 12 Contact



Telemotive AG

Office München  
Frankfurter Ring 115a  
80807 München

Tel.: +49 89 357186-0  
Fax.: +49 89 357186-520  
E-Mail: [info@telemotive.de](mailto:info@telemotive.de)  
Web: [www.telemotive.de](http://www.telemotive.de)

Sales  
Tel.: +49 89 357186-550  
Fax.: +49 89 357186-520  
E-Mail: [sales@telemotive.de](mailto:sales@telemotive.de)

Support  
Tel.: +49 89 357186-518  
E-Mail: [productsupport@telemotive.de](mailto:productsupport@telemotive.de)  
ServiceCenter: <https://sc.telemotive.de/bluepirat>