

blue PiraT2

ESO Trace User Guide

Version 1.9.1 - 29.01.2014



Index

1.	LICENSE AGREEMENT	2
2.	PRODUCT LIABILITY	3
3.	Overwiev	4
4.	System requirements	4
5.	Configuration	5
5.1.	Configuration menu	5
5.2.	Configuration of an Ethernet Channel for ESO Trace	6
5.2.1.	Activate Ethernet interface.....	6
5.2.2.	Name, Connector and Protocol	6
5.2.3.	Target Configuration	7
6.	Data Download & Converting	8
7.	Contact	9

1. LICENSE AGREEMENT

Please read the license agreement of this license contract carefully, before you install the software. By the installation of the software you agree to the conditions of this license contract.

This software-license agreement, in the following called as " license", contains all rights and restrictions for final users that regulate the use of the accompanying software, operating instructions and other documents, in the following called as "software".

1. This license contract is an agreement between Licensor and Licensee, who is being licensed to use the named Software.
2. Licensee acknowledges that this is only a limited nonexclusive license. This means that the licensee has no right to allocate sublicenses. Licensor is and remains the owner of all titles, rights, and interests in the Software.
3. The software is a copyright property of the Telemotive AG. The program or parts of it may not be further licensed to third parts, rented, sells, or be further marketed, otherwise, in any form without explicit Written approval by Telemotive AG. The user may neither change the software and their components, modify nor, otherwise, redevelopment or decompile in any form.
4. This Software is subject to no warranty. This software is sold as is, without any warranty. If at any time, a user changes their system, we hold no responsibility to change our software to make it work again.
5. This License permits Licensee to install the Software on more than one computer system, as long as the Software will not be used on more than one computer system simultaneously. Licensee will not make copies of the Software or allow copies of the Software to be made by others, unless authorized by this License Agreement. Licensee may make copies of the Software for backup purposes only. Licensee not entitled to transmit or to transfer the software or your rights from this License agreement.
6. LICENSOR IS NOT LIABLE TO LICENSEE FOR ANY DAMAGES, INCLUDING COMPENSATORY, SPECIAL, INCIDENTAL, EXEMPLARY, PUNITIVE, OR CONSEQUENTIAL DAMAGES, CONNECTED WITH OR RESULTING FROM THIS LICENSE AGREEMENT OR LICENSEE'S USE OF THIS SOFTWARE.
7. Licensee agrees to defend and indemnify Licensor and hold Licensor harmless from all claims, losses, damages, complaints, or expenses connected with or resulting from Licensee's business operations.
8. Licensor has the right to terminate this License Agreement and Licensee's right to use this Software upon any material breach by Licensee. duration of the license contract is indefinitely determined.
9. Licensee agrees to return to Licensor or to destroy all copies of the Software upon termination of the License Contract.
10. This License Agreement replaces and supersedes all prior negotiations, dealings, and agreements between Licensor and Licensee regarding this Software.
11. This License Contract is subject to german law.
12. If a regulation of this license contract is void by law, the validity of the remaining regulations is not affected. If there is such a regulation it will be replaced by a valid, according to the legal regulations and enforceable regulation with similar intention and similar economic consequences.
13. the license contract is effective by delivery of the software of the licensor to the licensee and/or by usage of the software by the licensee. This License contract is also valid without Licensor's signature.
14. The license automatically goes out if the licensee does not agree to the license regulations described here or offend against the license regulations of this license contract. With ending the license contract the licensee is obliged to extinguish all copies of the software or to destroy it.
15. The LICENSEE sticks for all damages which originates the licensor from the injury of these license regulations.

2. PRODUCT LIABILITY

For all offers, sales and supplies do explicit apply the following conditions, even if the buyer, orderer and suchlike prescribes other conditions. Alterations are only valid, if they are agreed in writing.

1. The technical documentation is part of the products. The product liability and the product guarantee will be excluded, if contents and in particular the safety references and instruction for action of the documentation are not considered.
2. The products do belong to the group of testtools. by application of the equipment a disturbance of the tested system cannot be completely excluded. For this reason, the warranty of a perfectly functioning system cannot be taken over by the manufacturer. Application of the product takes place at one's own risk.
3. The liability of the substitution of damages according to §1 product liability law, is expressly excluded in the context of §9 product liability law, as far as compelling legal terms do not provide anything else.
In no event will the producer be liable for any indirect, incidental, special or consequential damages, including loss of profits, loss of revenues, loss of data, loss of use, any other economic advantage or damages caused by pretensions of third party towards the customer out of this agreement, under any theory of liability, whether in an action in contract, strict liability, tort (including negligence) or other legal or equitable theory.
The burden of proof is with the customer.
4. The Telemotive AG does ensure the legal warranty according to German law.
Except for warranties expressly set forth in this agreement, any and all products are delivered "as is" and the producer makes and the customer receives no additional express or implied warranties. The producer hereby expressly disclaims any and all other warranties of any kind or nature concerning the products, whether express or implied, including without limitation, any warranty of title, merchantability, quality, accuracy, or fitness for a particular purpose or the customer's purpose. The producer expressly disclaims any warranties that may be implied form usage of trade, course of dealing, or course of performance, except for the express warranties stated in this agreement. The products are provided with all faults, and the entire risk of satisfactory quality, performance, accuracy, and effort is with customer. The producer does not warrant that the Products will operate without interruption or be error free.
5. The Telemotive AG is justified to exchange defective goods against homogeneous acceptable ones or to eliminate the fault within an appropriate period. In this case a demand for redhibitory action or reduction of price expires. Warranty claims presuppose a due notice of defects.
6. Resale, transfer, donation, exchanges or the rental of the offered products at third party, is permitted without clearance of the Telemotive AG.
7. German Law is deemed to be as legal basis.

3. Overview

The “ESO Trace” feature of the blue PiraT2 enables the following options:

- Logging of ESO Trace Ethernet data
- Conversion of recorded data into JSON format

A license is required to use the ESO Trace feature. All steps can be performed only with a valid license.

With the ESO Trace license it is possible to log Ethernet raw data, especially coming from an ESO Trace Device (e.solution Tracing Framework device). The logger is part of a client-server architecture where the blue PiraT2 is the client that logs the TCP-raw ESO Trace stream.

This quick reference guide only describes the configuration and usage of ESO Trace logging. For more information about Ethernet logging please have a look at the blue PiraT2 manual.

This document refers to blue PiraT2 FW 01.09.01 and blue PiraT2 client version 1.9.1. Some features depending on model and feature license or may not be available in older versions.

Software updates are frequently available in the blue PiraT Service Center. Please make sure to use current software.

4. System requirements

Control Unit

A Laptop or a PC is used to configure the devices by a software client. It also allows to save the recorded data and to use them offline.

blue PiraT2

The blue PiraT2 is an optimized data logger developed by Telemotive AG. The communication of bus systems and control units are monitored and relevant data can be recorded very precisely with the blue PiraT2. The collected data are stored on the blue PiraT2 and can be downloaded to a PC.

License


The ESO Trace function works on any blue PiraT2 system. However, it is necessary to install a special license for this feature. For further information about licenses and license handling please have a look at the blue PiraT2 manual.

blue PiraT2. The collected data are stored on the blue PiraT2 and can be downloaded to a PC

5. Configuration

For the configuration of the ESO Trace feature, a connection to the data logger is required. Please connect the data logger to your computer and start the client.

In the client please open the logger configuration and choose the sub menu “Ethernet” from the selection tree.




The complete data logger configuration can be managed by following buttons:

Default configuration	Load a default configuration
Load from file	Load data from a locally stored configuration file
Save as file	Save the current configuration to a local file
Write to logger	Send the configuration to the connected data logger

The configuration is applied immediately

5.1. Configuration menu

In the client the configuration of the logger must be opened to configure the ESO Trace function. If the license has been installed properly, the selection tree shows the entries “Ethernet #1 to #8”. In the “Protocol” dropdown menu the entry “ESO Trace” is now available.




5.2. Configuration of an Ethernet Channel for ESO Trace

In the blue PiraT2 there are 8 channels available for the ESO Trace configuration. Each channel can be configured for logging ESO Trace.

5.2.1. Activate Ethernet interface

Each Ethernet interface that will be used for logging can be activated or deactivated separately.



5.2.2. Name, Connector and Protocol

Name:


You can configure a new name for each Ethernet channel.

Connector:

- Front Connector (1GBit/s): The Front Connector is used to log the ESO Trace data. Ethernet data will be stored in the chosen blue PiraT2 Ethernet channel.
- Back Connector (100MBit/s): The Back Connector is used to log the ESO Trace data. Ethernet data will be stored in the chosen blue PiraT2 Ethernet channel.

Protocol:

For the ESO Trace configuration please choose the “EsoTrace” protocol from the dropdown menu.



The screenshot shows a configuration window titled "Ethernet #1". It contains the following fields:

- Ethernet interface active
- Name: Ethernet-1
- Connector: Front (1 GBit/s)
- Protocol: EsoTrace

5.2.3. Target Configuration

Target IP address / port:

Configure the target IP address and the port of the device the blue PiraT2 should establish a connection to.

VLAN settings:

If the target device is inside a virtual LAN, the VLAN interface must be activated and the VLAN ID must be configured.

Additional IP-alias of the data logger:


If target IP address and IP address of the data logger (see General/Network settings) are not in the same subnet, you have to configure an “Additional IP-alias” which is in the subnet of the target device.

Note:

The IP address of the data logger and the IP address of the target device have to be in the same subnet.

Timeout:

This parameter configures the period after a reconnect to the target device follows. If there is a defined period no data received (timeout) this will be detected by the blue PiraT2 and a new connection will be established. For example: If there is no ESO Trace data detected by the blue PiraT2 for 30 seconds a reconnect will be started.



The screenshot shows a configuration window with the following fields:

- Target IP address: 192 . 168 . 0 . 101
- Port: 851
- VLAN settings:
 - VLAN interface active
 - VLAN ID: 1
- Additional IP-alias of the data logger:
 - IP-address of data logger: 192 . 168 . 0 . 234
 - Subnet mask: 255 . 255 . 255 . 0
- Timeout: 30 s (0 = no Timeout)

If everything is configured correctly the configuration has to be written to the data-logger (button "Write to logger").

Ethernet #1

Ethernet interface active

Name: Ethernet-1

Connector: Front (1 GBit/s)

Protocol: EsoTrace

Target IP address: 192 . 168 . 0 . 101

Port: 851

VLAN settings

VLAN interface active

VLAN ID: 1

Additional IP-alias of the data logger

IP-address of data logger: 192 . 168 . 0 . 234

Subnet mask: 255 . 255 . 255 . 0

Timeout: 30 s (0 = no Timeout)

Default configuration Load from file... Save as file... Read from logger Write to logger

6. Data Download & Converting

For data download and converting data please have a look at the blue PiraT2 manual.

7. Contact



Telemotive AG

Office München
Frankfurter Ring 115a
80807 München

Tel.: +49 89 357 186-0
Fax.: +49 89 357 186-520
E-Mail: info@telemotive.de
Web: www.telemotive.de

Vertrieb
Tel.: +49 89 357 186-550
Fax.: +49 89 357 186-520
E-Mail: sales@telemotive.de

Support
Tel.: +49 89 357 186-518
E-Mail: produktsupport@telemotive.de
ServiceCenter: <https://sc.telemotive.de/bluepirat>